



Maintenance and Service Guide

HP OmniBook X Flip 16 inch 2-in-1 Laptop
Next Gen AI PC: Model Number: 16-cc0xxx

HP OmniBook X Flip 16 inch 2-in-1 Laptop
Next Gen AI PC: Model Number: 16-cb0xxx

SUMMARY

This guide provides maintenance information about such topics as spare parts, removal and replacement of parts, security, and backing up.

Legal information

© Copyright 2026 HP Development Company, L.P.

Bluetooth is a trademark owned by its proprietor and used by HP Inc. under license. ChromeOS is a trademark of Google LLC. Intel, Arc, Core, and Thunderbolt are trademarks of Intel Corporation or its subsidiaries in the U.S. and/or other countries. Microsoft, Windows and Windows Hello are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. DisplayPort and the DisplayPort logo are trademarks owned by the Video Electronics Standards Association (VESA) in the United States and other countries. USB Type-C, USB-C, and the USB 10 Gbps, and USB 40 Gbps port logos are trademarks or registered trademarks of USB Implementers Forum. Miracast and Wi-Fi are registered trademarks of Wi-Fi Alliance.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

First Edition: January 2026

Document Part Number: P73657-001

Product notice

This guide describes features that are common to most models. Some features may not be available on your computer.

Not all features are available in all editions or versions of Windows. Systems may require upgraded and/or separately purchased hardware, drivers, software or BIOS update to take full advantage of Windows functionality. Windows is automatically updated, which is always enabled. High-speed internet and Microsoft account required. ISP fees may apply and additional requirements may apply over time for updates. See <http://www.microsoft.com>.

If your product ships with Windows in S

Mode: Windows in S Mode works exclusively with apps from the Microsoft Store within Windows. Certain default settings, features, and apps cannot be changed. Some accessories and apps that are compatible with Windows may not work (including some antivirus, PDF writers, driver utilities, and accessibility apps), and performance may vary, even if you switch out of S Mode. If you switch to Windows, you cannot switch back to S Mode. Learn more at Windows.com/SmodeFAQ.

To access the latest user guides, go to <http://www.hp.com/support>, and follow the instructions to find your product. Then select **Setup & User Guides**.

Software terms

By installing, copying, downloading, or otherwise using any software product preinstalled on this computer, you agree to be bound by the terms of the HP End User License Agreement (EULA). If you do not accept these license terms, your sole remedy is to return the entire unused product (hardware and software) within 14 days for a full refund subject to the refund policy of your seller.

For any further information or to request a full refund of the price of the computer, please contact your seller.

Safety warning notice

Reduce the possibility of heat-related injuries or of overheating the computer by following the practices described.

 **WARNING!** To reduce the possibility of heat-related injuries or of overheating the mobile computer, do not place the mobile computer directly on your lap or obstruct the computer air vents. Use the mobile computer only on a hard, flat surface. Do not allow another hard surface, such as an adjoining optional printer; or a soft surface, such as pillows, rugs, or clothing, to block airflow. Also, do not allow the AC adapter to contact the skin or a soft surface, such as pillows, or rugs or clothing, during operation. The computer and AC adapter provided by HP comply with the user-accessible surface temperature limits defined by applicable safety standards.

Important notice about Customer Self-Repair parts

Your computer includes Customer Self-Repair parts and parts that should be accessed only by an authorized service provider.



IMPORTANT: See [Removal and replacement procedures for Customer Self-Repair parts on page 31](#) for details.

Accessing parts described in [Removal and replacement procedures for authorized service provider parts on page 41](#) can damage the computer or void your warranty.

Table of contents

1 Product description.....	1
2 Getting to know your computer	5
Right side	5
Left side.....	6
Display	8
Low blue light mode (select products only).....	8
Wake-on-voice (select products only).....	8
Keyboard area	10
Touchpad settings and components	10
Touchpad settings	10
Adjusting touchpad settings.....	10
Turning on the touchpad	10
Touchpad components	10
Lights	11
Special keys	13
Rear	14
Bottom	15
360 mode.....	15
Labels	16
3 Illustrated parts catalog	17
Computer major components.....	17
Display assembly subcomponents.....	21
Miscellaneous parts.....	22
4 Removal and replacement procedures preliminary requirements.....	23
Tools required	23
Service considerations.....	23
Plastic parts.....	23
Cables and connectors.....	23
Drive handling	23
Electrostatic discharge information.....	24
Generating static electricity.....	24
Preventing electrostatic damage to equipment.....	25
Personal grounding methods and equipment.....	25
Grounding the work area.....	26
Recommended materials and equipment.....	26
Cleaning your computer	27
Enabling HP Easy Clean (select products only)	27

Removing dirt and debris from your computer.....	27
Cleaning your computer with a disinfectant.....	28
Caring for wood veneer (select products only).....	29
Packaging and transporting guidelines.....	29
Accessing support information.....	29
5 Removal and replacement procedures for Customer Self-Repair parts	31
Component replacement procedures	31
Preparation for disassembly.....	31
Bottom cover	31
Battery.....	34
Removing and reinstalling the same battery	34
Installing a new battery.....	35
6 Removal and replacement procedures for authorized service provider parts.....	41
Component replacement procedures	41
Solid-state drive.....	41
Speakers.....	43
Fan.....	44
I/O board.....	45
WLAN module.....	47
Touchpad	49
System board	50
Heat sink	53
Infrared (IR) sensor board.....	55
Display assembly.....	56
Keyboard with top cover	68
7 Backing up, restoring, and recovering.....	70
Backing up information and creating recovery media.....	70
Using Windows tools for backing up.....	70
Using the HP Cloud Recovery Download Tool to create a recovery USB flash drive (select products only).....	70
Restoring and recovering your system.....	70
Creating a system restore	71
Restoring and recovery methods	71
Recovering using the HP Recovery USB flash drive	71
Changing the computer boot order	72
Using HP Sure Recover (select products only).....	72
8 Using Setup Utility (BIOS).....	73
Starting Setup Utility (BIOS).....	73
Updating Setup Utility (BIOS).....	73
Determining the BIOS version.....	73
Preparing for a BIOS update	74
Downloading a BIOS update	74
Installing a BIOS update	75
9 Using HP PC Hardware Diagnostics	76

Using HP PC Hardware Diagnostics Windows (select products only)	76
Using an HP PC Hardware Diagnostics Windows hardware failure ID code.....	76
Accessing HP PC Hardware Diagnostics Windows	76
Accessing HP PC Hardware Diagnostics Windows from HP Support Assistant (select products only)	76
Accessing HP PC Hardware Diagnostics Windows from the Start menu (select products only).....	77
Downloading HP PC Hardware Diagnostics Windows	77
Downloading the latest HP PC Hardware Diagnostics Windows version from HP.....	77
Downloading the HP PC Hardware Diagnostics Windows from the Microsoft Store.....	77
Downloading HP Hardware Diagnostics Windows by product name or number (select products only)	78
Installing HP PC Hardware Diagnostics Windows	78
Using HP PC Hardware Diagnostics UEFI	78
Using an HP PC Hardware Diagnostics UEFI hardware failure ID code.....	78
Starting HP PC Hardware Diagnostics UEFI	78
Starting HP PC Hardware Diagnostics UEFI through HP Hotkey Support software (select products only).....	79
Downloading HP PC Hardware Diagnostics UEFI to a USB flash drive	79
Downloading the latest HP PC Hardware Diagnostics UEFI version	80
Downloading HP PC Hardware Diagnostics UEFI by product name or number (select products only)	80
Using Remote HP PC Hardware Diagnostics UEFI settings (select products only).....	80
Downloading Remote HP PC Hardware Diagnostics UEFI	80
Downloading the latest Remote HP PC Hardware Diagnostics UEFI version	80
Downloading Remote HP PC Hardware Diagnostics UEFI by product name or number.....	81
Customizing Remote HP PC Hardware Diagnostics UEFI settings.....	81
10 Specifications	82
Computer specifications.....	82
Display specifications.....	83
Solid-state drive specifications	83
11 Power cord set requirements.....	85
Requirements for all countries	85
Requirements for specific countries and regions.....	85
12 Swelling or deformation of notebook battery	88
Swollen notebook batteries	88
Swollen battery is not a safety issue	88
Discontinue using a swollen battery	88
Replace a swollen battery	88
Minimize battery swelling.....	88
Adaptive Battery Optimizer (consumer notebooks).....	89
HP Battery Health Manager (commercial notebooks)	89
13 Recycling.....	90
Index.....	91

1 Product description

This table provides detailed product information.



NOTE: For the latest specifications related to your computer, go to <http://www.hp.com/support> and follow the instructions to find your product. Select **Specifications & Accessories**, select **Product information**, and then select the specifications link.

Table 1-1 Product components and their descriptions

Category	Description
Product Name	HP OmniBook X Flip 16 Inch 2-In-1 Laptop Next Gen AI PC AMD® model number: 16-cc0xxx Intel® model number: 16-cb0xxx
Processors	AMD Ryzen™ processors AMD Ryzen AI 5 430, FP 8, 4.50 GHz, 8 MB cache, 4 cores, 54 watt accelerated processing unit (APU) AMD Ryzen AI 5 435, 4.50 GHz, 8 MB cache, 6 cores, 54 watt APU AMD Ryzen AI 7 450, 5.10 GHz, 16 MB cache, 8 cores, 54 watt APU AMD Ryzen AI 9 465, 5.00 GHz, 24 MB cache, 10 cores, 54 watt APU Intel Core™ processors Intel Core Ultra9 386H Intel Core Ultra7 356H Intel Core Ultra7 355 Intel Core Ultra5 325
Graphics	AMD graphics AMD Radeon 860M AMD Radeon 840M AMD Radeon™ 880M Intel graphics Intel Arc™ 140V 16 GB (Ultra 9 386H/Ultra7 356H processor) Intel Arc 140V 8 GB (Ultra7 355 processor) Intel Arc 130V 8 GB (Ultra5 325 processor) Supports HD Decode, DX12, and HDMI FreeSync™ (internal and external) (WUXGA LCD panels only) Support FreeSync Premium Pro (internal and external) (2.8K OLED panels only)
Display	16.0 in (40.64 cm), 2.8 K (2880 × 1800), organic light-emitting diode (OLED), bent, 100% DCI-P3, BrightView, narrow bezel, low blue light, ultrawide viewing angle (UWVA), embedded DisplayPort (eDP) 1.5 + panel self-refresh (PSR), 500 nits (SDR), 1100 nits (HDR), 120 Hz (VRR), touch screen

Table 1-1 Product components and their descriptions (continued)

Category	Description
	16.0 in (40.64 cm), 2.8 K (2880 × 1800), OLED, bent, 100% DCI-P3, BrightView, narrow bezel, low blue light, ultrawide viewing angle (UWVA), embedded DisplayPort™ (eDP) 1.5 + panel self-refresh (PSR), 500 nits, 30-120 Hz (VRR), touch screen
	16.0 in (40.64 cm), widescreen ultra extended graphics array (WUXGA+), (1920 × 1200), BrightView, flush glass, narrow bezel, OLED, low blue light, UWVA, 95% sRGB, eDP 1.2 without PSR, touch screen, 300 nits
	16.0 in (40.64 cm), WUXGA (1920 × 1200), BrightView, flush glass, narrow bezel, UWVA, 100% sRGB, eDP 1.2 without PSR, touch screen, 400 nits
	16:10 aspect ratio
	Panel certification (TUV + EyeSafe) (2.8K OLED panels only)
	Eye Ease label (2.8K OLED panels only)
	Flicker free
	MSFT HDR streaming capable
	MSFT DRR (Dynamic Refresh Rate) (2.8K OLED panels only)
	Supports Active Stylus with Windows Ink Logo
	Supports Simultaneous Pen & Touch
	Microsoft HDR streaming capable
	Supports Wake on Touch (WoT)
	Screen-to-body ratio: 90.73%
Memory	On-board system memory, not accessible or upgradeable
	DDR5-5200 dual-channel support
	Low-power double data rate (LPDDR) - LPDDR5x-8533
	Supports the following configurations:
	32 GB (LPDDR5-8533)
	24 GB (LPDDR5-8533)
	16 GB (LPDDR5-8533)
Primary storage	PCIe, (Non-Volatile Memory Express) NVMe, M.2 2280 solid-state drives (SSDs)
	2 TB
	1 TB
	512 GB
Audio and video	Dual speakers
	Supports speaker swap
	Poly Studio
	DTS:X Ultra
	HP Audio Boost 2.0
	HP Wide Vision HD Camera: AI integrated, USB2, indicator LED, 1 × infrared (IR) LED, f2.0, 5 MP back-illuminated (BSI) sensor, WDR/TNR/HDR, 88° wide field-of-view (WFOV)

Table 1-1 Product components and their descriptions (continued)

Category	Description
	5 MP by 30 frames per second
	Dual-array digital microphone with appropriate software: beam forming, echo cancellation, noise suppression
	Supports Windows Hello®
Wireless	Integrated wireless module with dual antennas
	AMD models
	Realtek 8922AE Wi-Fi® 7 + Bluetooth® 6.0 WLAN, worldwide
	Intel models
	MediaTek MT7925 Wi-Fi 7 + Bluetooth 6.0 AIM-T WLAN, worldwide
	Intel Wi-Fi 7 R2 BE211 + Bluetooth 6.0 WLAN, worldwide
	Compatible with Miracast® devices
	Supports Modern Standby (connected)
	Bluetooth Audio Offload
	Bluetooth LE Audio
	Wi-Fi BIOS specific absorption rate (SAR)
	Dynamic antenna gain (Wi-Fi)
	Dynamic antenna gain (BT)
	UNII-4 5 GHz channel
	WLAN Time Average SAR (TAS)
Ports	Audio-out (headphone)/audio-in (microphone) combo jack
	HDMI v2.1 supporting: up to 4K @ 60 Hz with HDCP 2.2
	2 USB 3.2 Gen 2 Type A (left and right sides)
	2 USB4 Type-C® (left and right sides), support:
	AMD models
	- DisplayPort 2.1 out up to 5 K @ 60 Hz (Ryzen AI processors) and HDMI 2.1 out with adapter
	Intel models
	- Thunderbolt™ 4, supports DisplayPort 1.4 out up to 8 K @ 60 Hz and HDMI 2.1 out with adapter
	- Power delivery 3.1
	- Data transfer
	- HDMI 2.1 output up to 4 K @ 60 Hz with HDCP 2.2 with adapter capable of HDMI 2.1
	- HP Sleep & Charge
Keyboard/pointing devices	Keyboard
	Backlit
	Integrated power button

Table 1-1 Product components and their descriptions (continued)

Category	Description
	Clickpad with image sensor
	Multitouch gestures enabled
	Precision touchpad support
	Taps enabled as default
	Modern trackpad gestures
Power requirements	Battery
	4 cell, 70 Whr, polymer, HP Long Life
	4 cell, 76 Whr, polymer, HP Long Life
	HP Fast Charge Technology
	Smart AC adapters
	HP 65 W GaN USB-C Wall Mount Fixed AC Power Adapter
	Power cord
	Non-Standard Black Straight HF Duckhead
Security	Supports Trusted Platform Module (TPM) 2.0, firmware based
	Microphone mute
	Camera privacy cover
Sensors	Accelerometer × 2
	Accelerometer + Gyroscope
	IR thermal sensor
	Sensor hub
Operating system	Windows 11 Pro
	Windows 11 Home 64 NextGen Premium
	Windows 11 Pro 64 NextGen Premium
	Windows 11 Home 64 NextGen Standard Single Language Africa Market PPP
	Windows 11 Home 64 NextGen Standard
	Windows 11 Pro 64 NextGen Standard
	Windows 11 Home 64 NextGen Premium Single Language Africa Market PPP
	Windows 11 Home 64 NextGen Premium
Serviceability	End user replaceable parts
	AC adapter
	Bottom cover
	Battery

2 Getting to know your computer

Your computer features top-rated components. This chapter provides details about your components, where they are located, and how they work.

Right side

Use these illustrations and table to identify the components on the right side of the computer.

 **NOTE:** Your computer might look slightly different from the illustrations in this section. Refer to the illustration that most closely matches your computer.




Table 2-1 Right-side components and their descriptions

	Component	Description
(1)	Magnetic pen attachment area	Holds an optional pen.
(2)	AC adapter and battery light	- White: The AC adapter is connected and the battery is fully charged. - Blinking amber: The AC adapter is disconnected and the battery has reached a low battery level. - Amber: The AC adapter is connected and the battery is charging. - Off: The battery is not charging.
(3)	 USB Type-C® power connector and Thunderbolt port with HP Sleep and Charge and DisplayPort output	Connects an AC adapter that has a USB Type-C connector, supplying power to the computer and, if needed, charging the computer battery. - and - Connects a USB device, provides high-speed data transfer, and charges small devices (such as a smartphone), even when the computer is off. NOTE: Use a standard USB Type-C charging cable or cable adapter (purchased separately) when charging a small external device. - and - Connects a display device that has a USB Type-C connector, providing DisplayPort output. NOTE: Your computer might also support a Thunderbolt docking station.

Table 2-1 Right-side components and their descriptions (continued)

	Component	Description
(4)	USB 10 Gbps port	Connects a USB device, provides high-speed data transfer, and (for select products) charges small devices (such as a smartphone) when the computer is on or in sleep mode. NOTE: Use a standard USB Type-A charging cable or cable adapter (purchased separately) when charging a small external device.
(5)	USB Type-C power connector and 40 Gbps port with HP Sleep and Charge and DisplayPort output	Connects an AC adapter that has a USB Type-C connector, supplying power to the computer and, if needed, charging the computer battery. - and - Connects a USB device, provides high-speed data transfer, and charges small devices (such as a smartphone), even when the computer is off. NOTE: Use a standard USB Type-C charging cable or cable adapter (purchased separately) when charging a small external device. - and - Connects a display device that has a USB Type-C connector, providing DisplayPort output.

Left side

Use these illustrations and table to identify the components on the left side of the computer.



NOTE: Your computer might look slightly different from the illustrations in this section. Refer to the illustration that most closely matches your computer.




Table 2-2 Left-side components and their descriptions

	Component	Description
(1)	USB 10 Gbps port	Connects a USB device, provides high-speed data transfer, and (for select products) charges small devices (such as a smartphone) when the computer is on or in sleep mode. NOTE: Use a standard USB Type-A charging cable or cable adapter (purchased separately) when charging a small external device.
(2)	HDMI port	Connects an optional video or audio device, such as a high-definition television, any compatible digital or audio component, or a high-speed High-Definition Multimedia Interface (HDMI) device.

Table 2-2 Left-side components and their descriptions (continued)

	Component	Description
(3)	 USB Type-C power connector and Thunderbolt port with HP Sleep and Charge and DisplayPort output	Connects an AC adapter that has a USB Type-C connector, supplying power to the computer and, if needed, charging the computer battery. - and - Connects a USB device, provides high-speed data transfer, and charges small devices (such as a smartphone), even when the computer is off. NOTE: Use a standard USB Type-C charging cable or cable adapter (purchased separately) when charging a small external device. - and - Connects a display device that has a USB Type-C connector, providing DisplayPort output. NOTE: Your computer might also support a Thunderbolt docking station.
(4)	AC adapter and battery light	• White: The AC adapter is connected and the battery is fully charged. • Blinking amber: The AC adapter is disconnected and the battery has reached a low battery level. • Amber: The AC adapter is connected and the battery is charging. • Off: The battery is not charging.
(5)	Audio-out (headphone)/Audio-in (microphone) combo jack	Connects optional powered stereo speakers, headphones, earbuds, a headset, or a television audio cable. Also connects an optional headset microphone. This jack does not support optional standalone microphones. WARNING! To reduce the risk of personal injury, adjust the volume before putting on headphones, earbuds, or a headset. For additional safety information, see the <i>Regulatory, Safety, and Environmental Notices</i>. To access this guide: ■ Select the Search icon in the taskbar, type HP Documentation in the search box, and then select HP Documentation. NOTE: When a device is connected to the jack, the computer speakers are disabled.

Table 2-2 Left-side components and their descriptions (continued)

	Component	Description
(6)	USB Type-C power connector and 40 Gbps port with HP Sleep and Charge and DisplayPort output	Connects an AC adapter that has a USB Type-C connector, supplying power to the computer and, if needed, charging the computer battery. - and - Connects a USB device, provides high-speed data transfer, and charges small devices (such as a smartphone), even when the computer is off. NOTE: Use a standard USB Type-C charging cable or cable adapter (purchased separately) when charging a small external device. - and - Connects a display device that has a USB Type-C connector, providing DisplayPort output.

Display

The computer display can include essential components such as speakers, antennas, cameras, and microphones.

Low blue light mode (select products only)

Your computer display is shipped from the factory in low blue light mode for improved eye comfort and safety. Also, blue light mode automatically adjusts blue light emissions when you are using the computer at night or for reading.

 **WARNING!** To reduce the risk of serious injury, read the *Safety & Comfort Guide*. It describes proper workstation setup and proper posture, health, and work habits for computer users. The *Safety & Comfort Guide* also provides important electrical and mechanical safety information. The *Safety & Comfort Guide* is available on the web at <http://www.hp.com/ergo>.

Wake-on-voice (select products only)

Use the wake-on-voice feature to wake or interact with your computer quickly.

To access the wake-on-voice settings, follow these steps:

1. Select the **Search** icon in the taskbar, type **Xiaowei** in the search box, and then select **Xiaowei**.
2. When the tool opens, scan the QR code with your mobile device, which takes you to the settings page, where you can select your wake-on-voice features.
3. Follow the on-screen instructions.

 **NOTE:** Allow the Xiaowei app to continue running on the computer.

Use this illustration and table to identify components on the display.




Table 2-3 Display components and their descriptions

	Component	Description
(1)	WLAN antennas* (2)	Send and receive wireless signals to communicate with wireless local area networks (WLANs).
(2)	Camera lights (2)	On: One or more cameras are in use.
(3)	Internal microphones (2)	Record sound.
(4)	Cameras (2)	Allow you to video chat, record video, and record still images. NOTE: Camera functions vary depending on the camera hardware and software installed on your product.
(5)	Camera privacy cover	By default, the camera lens is uncovered, but you can slide the camera privacy cover to block the camera's view. To use the camera, slide the camera privacy cover in the opposite direction to reveal the lens.

*The antennas are not visible from the outside of the computer. For optimal transmission, keep the areas immediately around the antennas free from obstructions.

For wireless regulatory notices, see the section of the *Regulatory, Safety, and Environmental Notices* that applies to your country or region.

To access this guide:

- Select the **Search** icon in the taskbar, type **HP Documentation** in the search box, and then select **HP Documentation**.

Keyboard area

Keyboards can vary by language.



NOTE: The keyboard area, including the function keys and (select products only) power key, is disabled in stand, tent, and tablet modes. To enable the keyboard, including the power key, change to the clamshell mode.

Touchpad settings and components

Learn the touchpad settings and components.

Touchpad settings

Learn how to adjust touchpad settings.

Adjusting touchpad settings

Use these steps to adjust touchpad settings and gestures.

1. Select the **Search** icon in the taskbar, type `touchpad settings` in the search box, and then press `enter`.
2. Choose a setting.

Turning on the touchpad

Follow these steps to turn on the touchpad.

1. Select the **Search** icon in the taskbar, type `touchpad settings` in the search box, and then press `enter`.
2. Using an external mouse, click the **touchpad** button.

If you are not using an external mouse, press the **Tab** key repeatedly until the pointer rests on the **touchpad** button. Then press the `spacebar` to select the button.

Touchpad components

Use this illustration and table to identify the touchpad components.




Table 2-4 Touchpad components and their descriptions

	Component	Description
(1)	Touchpad zone	Reads your finger gestures to move the pointer or activate items on the screen.
(2)	Brightness control	Drag your finger up or down to increase or decrease the screen brightness. NOTE: This feature is disabled by default. To enable brightness control on the touchpad, select Start , select Settings , select Bluetooth & devices , and then select Touchpad . Under Touchpad , turn on Enable gesture control .
(3)	Left touchpad button	Functions like the left button on an external mouse.
(4)	Right touchpad button	Functions like the right button on an external mouse.
(5)	Volume control	Drag your finger up or down to increase or decrease the speaker volume. NOTE: This feature is disabled by default. To enable volume control on the touchpad, select Start , select Settings , select Bluetooth & devices , and then select Touchpad . Under Touchpad , turn on Enable gesture control .

Lights

Use this illustration and table to identify the lights on the computer.




Table 2-5 Lights and their descriptions

	Component	Description
(1)	Caps lock light	On: Caps lock is on, which switches the key input to all capital letters.
(2)	 Mute light	- On: Computer sound is off. - Off: Computer sound is on.
(3)	 Microphone mute light	- On: Microphone is off. - Off: Microphone is on.
(4)	Num lk light	On: Num lk is on.
(5)	 Power light	- On: The computer is on. - Blinking (select products only): The computer is in the sleep state, a power-saving state. The computer shuts off power to the display and other unnecessary components. - Off: Depending on your computer model, the computer is off, in hibernation, or in sleep. Hibernation is the power-saving state that uses the least amount of power.
(6)	Fn lock light	- On: FN Lock is enabled. - Off: FN Lock is disabled. NOTE: On some products, FN Lock is assigned as the secondary function of the left Shift key. To enable FN Lock, press fn + left Shift. Repeat the same key combination again to disable FN Lock.

Special keys

Use this illustration to identify the special keys.




Table 2-6 Special keys and their descriptions

	Component	Description
(1) 	Calculator key	Opens the calculator.
(2)	<code>esc</code> key	Displays system information when pressed in combination with the <code>fn</code> key.
(3)	Dual action keys	• Main function: Displayed in a larger font size on the key. • Secondary function: Displayed in the corner of the key in a smaller font size. Activate the secondary function by pressing the <code>fn</code> key at the same time. NOTE: FN Lock status only affects the behavior of the f1 through f12 function keys.
(4)	<code>fn</code> key	Executes specific functions when pressed in combination with another key.
(5) 	Windows key	Opens the Start menu. NOTE: Pressing the Windows key again will close the Start menu.
(6)	Action keys	Execute frequently used system functions as defined by the icon symbols on <code>f1</code> through <code>f12</code> function keys.

Table 2-6 Special keys and their descriptions (continued)

	Component	Description
(7)	 Windows Copilot key	Opens Windows Copilot (select products only). NOTE: Copilot in Windows (select products only) requires Windows 11. Some features require a neural processing unit (NPU). The timing of feature delivery and availability varies by market and device. You must have a Microsoft account to use the Copilot feature. When the Copilot feature is not available, pressing the Copilot key opens the Bing search engine. See http://aka.ms/WindowsAIFeatures.
(8)	num lock key	Alternates between the navigational and numeric functions on the integrated numeric keypad.
(9)	Integrated numeric keypad	A separate keypad to the right of the alphabet keyboard. When num lock is pressed, the keypad can be used like an external numeric keypad. NOTE: If the keypad function is active when the computer is turned off, that function is reinstated when the computer is turned back on.
(10)	 Power button	• When the computer is off, press the button briefly to turn on the computer. • When the computer is on, press the button briefly to initiate sleep. • When the computer is in the sleep state, press the button briefly to exit sleep (select products only). • When the computer is in hibernation, press the button briefly to exit hibernation. IMPORTANT: Pressing and holding down the power button results in the loss of unsaved information. If the computer has stopped responding and shutdown procedures are ineffective, press and hold the power button down for at least 10 seconds to turn off the computer. To learn more about your power and sleep settings: ■ Right-click the Power icon , and then select Power and sleep settings.

Rear

Identify the rear component.



Table 2-7 Rear component and its description

Component	Description
Vent	Enables airflow to cool internal components. NOTE: The computer fan starts up automatically to cool internal components and prevent overheating. It is normal for the internal fan to cycle on and off during routine operation.

Bottom

Identify the bottom components.




Table 2-8 Bottom components and their descriptions

	Component	Description
(1)	Speakers (2)	Produce sound.
(2)	Vent	Enables airflow to cool internal components. NOTE: The computer fan starts up automatically to cool internal components and prevent overheating. It is normal for the internal fan to cycle on and off during routine operation.

360 mode

If your computer offers 360 mode, the following illustration shows how you can use and fold your device.



Labels

The labels affixed to the computer provide information that you might need when you troubleshoot system problems or travel internationally with the computer. Labels can be in paper form or imprinted on the product.

 **IMPORTANT:** Check the following locations for the labels described in this section: the bottom of the computer, inside the battery bay, under the service door, on the back of the display, or on the bottom of a tablet kickstand.

- **Service label**—Provides important information to identify your computer. When contacting support, you might be asked for the serial number, the product number, or the model number. Locate this information before you contact support.

Your service label will resemble the following example:




Table 2-9 Service label components

Component	
(1)	Serial number
(2)	Product ID
(3)	HP product name and model number

- **Regulatory labels**—Provide regulatory information about the computer.
- **Wireless certification labels**—Provide information about optional wireless devices and the approval markings for the countries or regions in which the devices have been approved for use.

3 Illustrated parts catalog

Use this chapter to determine the spare parts that are available for the computer.

Computer major components

Use this illustration and table to identify the computer major components.

 **NOTE:** HP continually improves and changes product parts. For complete and current information about supported parts for your computer, go to <https://partsurfer.hp.com/>, select your country or region, and then follow the on-screen instructions.

 **NOTE:** Details about your computer, including model, serial number, product key, and length of warranty, are on the service tag at the bottom of your computer.




Table 3-1 Computer major component descriptions and part numbers

Item	Component	Spare part number
(1)	Display assembly NOTE: Display spare parts are available as subcomponents, not as whole units. Display subcomponent spare parts are available. For spare part information, see Display assembly subcomponents on page 21 .	not available as a spare part
(2)	Top cover/keyboard NOTE: For a detailed list of country codes, see Keyboard with top cover on page 68 .	
	Atmospheric blue top cover, darker atmospheric blue opaque keyboard and clickpad, image sensor backlit keyboard	P92662-001
	Eclipse gray keyboard top cover, darker eclipse gray keyboard and clickpad, image sensor backlit keyboard	P92663-001

Table 3-1 Computer major component descriptions and part numbers (continued)

Item	Component	Spare part number
	Meteor silver top cover, darker meteor silver keyboard and clickpad, image sensor backlight keyboard	P92893-001
(3)	Touchpad	
	Atmospheric blue models	P92679-001
	Eclipse gray models	P92678-001
	Meteor silver models	P92879-001
(4)	WLAN module	
	MediaTek MT7925 Wi-Fi 7 Bluetooth 5.43	N64647-005
	Intel Wi-Fi 7 BE211 Bluetooth 6	P36621-005
	Realtek Chivas M.2 2230 Wi-Fi 7 +Bluetooth 6.0	P44408-005
(5)	Solid-state drive (SSD)	
	2 TB	P07215-005
		P73031-005
	1 TB	N77394-005
		P73030-005
	512 GB	N77392-005
		P73029-005
(6)	I/O board	
	Intel model	P96561-001
	AMD model	P92675-001
(7)	Battery (4 cell, 78, 70 Whr)	
	Battery, 4 cell, 78 Whr (includes revive kit)	P55091-001
	Battery, 4 cell, 70 Whr (includes revive kit)	P55092-001
	Battery cable (available in the Cable Kit)	P92665-001
(8)	Speakers (left and right)	P92685-001
(9)	Bottom cover	
	Bottom cover, atmospheric blue models	P92682-001
	Bottom cover, eclipse gray models	P92681-001
	Bottom cover, meteor silver models	P92898-001
(10)	Fan	P92683-001
(11)	Heat sink assembly	
	AMD models	P92899-001
	Intel models	P92684-001

Table 3-1 Computer major component descriptions and part numbers (continued)

Item	Component	Spare part number
(12)	System board (includes integrated processor)	
	NOTE: All system board spare part kits include replacement thermal material.	
	System board (includes processor; for use in models with an AMD processor).	
	AMD Ryzen AI 5 430 processor, 16 GB system memory	P92885-601
	AMD Ryzen AI 5 435 processor, 16 GB system memory	P92886-601
	AMD Ryzen AI 7 450 processor, 32 GB system memory	P92887-601
	AMD Ryzen AI 9 465 processor, 32 GB system memory	P92888-601
	AMD Ryzen AI 7 445 processor, 32 GB system memory	P92889-601
	AMD Ryzen AI 7 445 processor, 16 GB system memory	Q03247-601
	AMD Ryzen AI 7 450 processor, 24 GB system memory	Q06474-601
	AMD Ryzen AI 5 435 processor, 24 GB system memory	Q06476-601
	AMD Ryzen AI 7 445 processor, 24 GB system memory	Q06477-601
	System board (includes processor; for use in models with an Intel processor.)	
	Intel Core Ultra 9 386H processor, 32 GB system memory	P92652-601
	Intel Core Ultra 7 356H processor, 32 GB system memory	P92651-601
	Intel Core Ultra 7 355 processor, 16 GB system memory	P92649-601
	Intel Core Ultra 7 355 processor, 32 GB system memory	P92657-601
	Intel Core Ultra 7 355 processor, 32 GB system memory	Q06468-601
	Intel Core Ultra 5 325 processor, 24 GB system memory	Q06467-601
	Intel Core Ultra 7 355 processor, 24 GB system memory	Q06478-601
	Intel Core Ultra 7 355 processor, 24 GB system memory	Q06479-601
	System board (includes processor; for use in models with the Windows operating system in the People's Republic of China [PRC])	
	Intel Core Ultra 9 386H processor, 32 GB system memory	P92656-601
	Intel Core Ultra 7 356H processor, 32 GB system memory	P92655-601
	Intel Core Ultra 7 355 processor, 32 GB system memory	P92658-601
	Intel Core Ultra 7 355 processor, 16 GB system memory	P92654-601
	Intel Core Ultra 5 325 processor, 24 GB system memory	Q06480-601
	Intel Core Ultra 7 355 processor, 24 GB system memory	Q06481-601
	Intel Core Ultra 5 325 processor, 16 GB system memory	P92653-601
(13)	Infrared (IR) sensor board	
	NOTE: The IR sensor board cable is included.	
	AMD model	P96560-001
	Intel model	P92674-001

Display assembly subcomponents

To identify the display assembly subcomponents, use this illustration and table.




Table 3-2 Display component descriptions and part numbers

Item	Component	Spare part number
(1)	Display panel (Includes cable, panel stretchable tape, touch board tape and stretchable tape)	
	2.8 K, OLED	P92660-001
	WUXGA, LED	P92659-001
	WUOLED	P92661-001
(2)	Camera module (Includes cable, rubber piece, and panel stretchable tape)	P92680-001
(3)	Hinge covers (left and right, includes panel stretchable tape)	

Table 3-2 Display component descriptions and part numbers (continued)

Item	Component	Spare part number
	Atmospheric blue models	P92673-001
	Eclipse gray models	P92672-001
	Meteor silver models	P92896-001
(4)	Hinges (left and right, includes panel stretchable tape)	P92671-001
(5)	Wireless antenna kit (included in the Cable Kit)	P92665-001
(6)	Touch control board (includes display cable and panel stretchable tape)	P92676-001
(7)	OLED board (includes display cable, foil, thermal pad, and panel stretchable tape)	P92677-001
(8)	Camera cable (included in the Cable Kit)	P92665-001
(9)	Display panel cable (includes panel stretchable tape)	P92664-001
(10)	Display back cover (includes wireless antennas and panel stretchable tape)	
	OLED models with antenna (atmospheric blue)	P92670-001
	LED models with antenna (atmospheric blue)	P92669-001
	OLED models with antenna (eclipse gray)	P92668-001
	LED models with antenna (eclipse gray)	P92667-001
	OLED models with antenna (meteor silver)	P92895-001
	LED models with antenna (meteor silver)	P92894-001

Miscellaneous parts

To identify the miscellaneous parts, use this table.

Table 3-3 Miscellaneous part descriptions and part numbers

Component	Spare part number
AC adapters	
AC adapter (65 W, nPFC, GaN WM USB-C, WM, 2P)	P58629-001
AC adapter (65 W, nPFC, USB-C, WM, FX, 2P, 2.0M)	P58630-001
AC adapter (65W USB-C WM 2P)	P68491-001
Screw and Misc kit	P92666-001
Cable Kit (includes I/O board cable, IR sensor board cable, keyboard cable, touchpad cable, battery cable, camera cable, and wireless antennas and cables)	P92665-001
Pen	
Pen, black	N54711-001
Power cords (Non-standard duckhead straight connector, halogen free)	
Australia	P57784-001
Europe (Austria, Belgium, Finland, France, Germany, the Netherlands, Norway, and Sweden)	P57782-001
United Kingdom	P57783-001

4 Removal and replacement procedures preliminary requirements

Use this information to properly prepare to disassemble and reassemble the computer.

Tools required

You need the following tools to complete the removal and replacement procedures.

- Tweezers
- Nonconductive, nonmarking pry tool
- Magnetic Phillips P1 screwdriver

Service considerations

The following sections include some of the considerations that you must keep in mind during disassembly and assembly procedures.



NOTE: As you remove each subassembly from the computer, place the subassembly and all accompanying screws away from the work area to prevent damage.

Plastic parts

Using excessive force during disassembly and reassembly can damage plastic parts.

Cables and connectors

Handle cables with extreme care to avoid damage.



IMPORTANT: When servicing the computer, be sure that cables are placed in their proper locations during the reassembly process. Improper cable placement can damage the computer.

Apply only the tension required to unseat or seat the cables during removal and insertion. Handle cables by the connector whenever possible. In all cases, avoid bending, twisting, or tearing cables. Be sure that cables are routed so that they cannot be caught or snagged as you remove or replace parts. Handle flex cables with extreme care; these cables tear easily.

Drive handling

Note the following guidelines when handling drives.



IMPORTANT: Drives are fragile components. Handle them with care. To prevent damage to the computer, damage to a drive, or loss of information, observe these precautions:

- Before removing or inserting a hard drive, shut down the computer. If you are unsure whether the computer is off or in hibernation or sleep mode, turn the computer on, and then shut it down through the operating system.

- Before handling a drive, be sure that you are discharged of static electricity. While handling a drive, avoid touching the connector.
 - Before removing an optical drive, be sure that a disc is not in the drive, and be sure that the optical drive tray is closed.
 - Handle drives on surfaces covered with at least 2.54 cm (1 inch) of shock-proof foam.
 - Avoid dropping drives from any height onto any surface.
 - After removing a hard drive or an optical drive, place it in a static-proof bag.
 - Avoid exposing an internal hard drive to products that have magnetic fields, such as monitors or speakers.
 - Avoid exposing a drive to temperature extremes or liquids.
 - If a drive must be mailed, place the drive in a bubble pack mailer or other suitable form of protective packaging, and label the package "FRAGILE."
-

Electrostatic discharge information

A sudden discharge of static electricity from your finger or other conductor can destroy static-sensitive devices or microcircuitry. Often the spark is neither felt nor heard, but damage occurs. An electronic device exposed to electrostatic discharge (ESD) might not appear to be affected at all and can work perfectly throughout a normal cycle. The device might function normally for a while, but it has been degraded in the internal layers, reducing its life expectancy.

Networks built into many integrated circuits provide some protection, but in many cases, the discharge contains enough power to alter device parameters or melt silicon junctions.



IMPORTANT: To prevent damage to the device when you remove or install internal components, observe these precautions:

- Keep components in their electrostatic-safe containers until you are ready to install them.
 - Before touching an electronic component, discharge static electricity by using the guidelines described in [Personal grounding methods and equipment on page 25](#).
 - Avoid touching pins, leads, and circuitry. Handle electronic components as little as possible.
 - If you remove a component, place it in an electrostatic-safe container.
-

Generating static electricity

Follow these static electricity guidelines.

- Different activities generate different amounts of static electricity.
- Static electricity increases as humidity decreases.

Table 4-1 Static electricity occurrence based on activity and humidity

Event	55% relative humidity	40% relative humidity	10% relative humidity
Walking across carpet	7500 V	15,000 V	35,000 V
Walking across vinyl floor	3000 V	5000 V	12,000 V
Motions of bench worker	400 V	800 V	6000 V
Removing dual in-line packages (DIPs) from plastic tube	400 V	700 V	2000 V
Removing DIPs from vinyl tray	2000 V	4000 V	11,500 V
Removing DIPs from polystyrene foam	3500 V	5000 V	14,500 V
Removing bubble pack from PCB (printed circuit board)	7000 V	20,000 V	26,500 V
Packing PCBs in foam-lined box	5000 V	11,000 V	21,000 V

 **NOTE:** Multiple electric components can be packaged together in plastic tubes, trays, or polystyrene foam.

 **NOTE:** As little as 700 V of static electricity can degrade a product.

Preventing electrostatic damage to equipment

Many electronic components are sensitive to ESD. Circuitry design and structure determine the degree of sensitivity.

The following packaging and grounding precautions are necessary to prevent static electricity damage to electronic components:

- To avoid hand contact, transport products in static-safe containers such as tubes, bags, or boxes.
- Protect all electrostatic parts and assemblies with conductive or approved containers or packaging.
- Keep electrostatic-sensitive parts in their containers until they arrive at static-free stations.
- Place items on a grounded surface before removing them from their container.
- Always be properly grounded when touching a sensitive component or assembly.
- Avoid contact with pins, leads, or circuitry.
- Place reusable electrostatic-sensitive parts from assemblies in protective packaging or conductive foam.

Personal grounding methods and equipment

Using certain equipment can prevent static electricity damage to electronic components.

- **Wrist straps** are flexible straps with a maximum of $1\text{ M}\Omega \pm 10\%$ resistance in the ground cords. To provide proper ground, wear a strap snug against bare skin. Verify that the ground cord is connected and fits snugly into the banana plug connector on the grounding mat or workstation.
- You can use **heel straps, toe straps, and boot straps** at standing workstations. These straps are compatible with most types of shoes or boots. On conductive floors or dissipative floor mats, use them on both feet with a maximum of $1\text{ M}\Omega \pm 10\%$ resistance between the operator and ground.

Table 4-2 Static shielding protection levels

Method	Voltage
Antistatic plastic	1500
Carbon-loaded plastic	7500
Metalized laminate	15,000

Grounding the work area

To prevent static damage at the work area, follow these precautions.

- Cover the work surface with approved static-dissipative material.
- Use a wrist strap connected to a properly grounded work surface and use properly grounded tools and equipment.
- Use static-dissipative mats, foot straps, or air ionizers to give added protection.
- Handle electrostatic sensitive components, parts, and assemblies by the case or PCB laminate. Handle them only at static-free work areas.
- Turn off power and input signals before inserting and removing connectors or test equipment.
- Use fixtures made of static-safe materials when fixtures must directly contact dissipative surfaces.
- Keep the work area free of nonconductive materials, such as ordinary plastic assembly aids and polystyrene foam.
- Use conductive field service tools, such as cutters, screwdrivers, and vacuums.
- Avoid contact with pins, leads, or circuitry.

Recommended materials and equipment

HP recommends certain materials and equipment to prevent static electricity.

- Antistatic tape
- Antistatic smocks, aprons, or sleeve protectors
- Conductive bins and other assembly or soldering aids
- Conductive foam
- Conductive tabletop workstations with ground cord of $1\text{ M}\Omega \pm 10\%$ resistance
- Static-dissipative table or floor mats with hard tie to ground
- Field service kits
- Static awareness labels
- Wrist straps and footwear straps providing $1\text{ M}\Omega \pm 10\%$ resistance
- Material handling packages
- Conductive plastic bags

- Conductive plastic tubes
- Conductive tote boxes
- Opaque shielding bags
- Transparent metallized shielding bags
- Transparent shielding tubes

Cleaning your computer

Cleaning your computer regularly removes dirt and debris so that your device continues to operate at its best. Use the following information to safely clean the external surfaces of your computer.

Enabling HP Easy Clean (select products only)

HP Easy Clean helps you to avoid accidental input while you clean the computer surfaces. This software disables devices such as the keyboard, touch screen, and touchpad for a preset amount of time so that you can clean all computer surfaces.

1. Start HP Easy Clean in one of the following ways:
 - Select the **Start** menu, and then select **HP Easy Clean**.
 - Select the **HP Easy Clean** icon in the taskbar.
 - Select **Start**, and then select the **HP Easy Clean** tile.
2. Now that your device is disabled for a short period, see [Removing dirt and debris from your computer on page 27](#) for the recommended steps to clean the high-touch, external surfaces on your computer. After you remove the dirt and debris, you can also clean the surfaces with a disinfectant. See [Cleaning your computer with a disinfectant on page 28](#) for guidelines to help prevent the spread of harmful bacteria and viruses.

Removing dirt and debris from your computer

Here are the recommended steps to clean dirt and debris from your computer.

For computers with wood veneer, see [Caring for wood veneer \(select products only\) on page 29](#).

1. Wear disposable gloves made of latex (or nitrile gloves, if you are latex-sensitive) when cleaning the surfaces.
2. Turn off your device and unplug the power cord and other connected external devices. Remove any installed batteries from items such as wireless keyboards.

 **CAUTION:** To prevent electric shock or damage to components, never clean a product while it is turned on or plugged in.

3. Moisten a microfiber cloth with water. The cloth should be moist, but not dripping wet.

 **IMPORTANT:** To avoid damaging the surface, avoid abrasive cloths, towels, and paper towels.

4. Wipe the exterior of the product gently with the moistened cloth.



IMPORTANT: Keep liquids away from the product. Avoid getting moisture in any openings. If liquid makes its way inside your HP product, it can cause damage to the product. Do not spray liquids directly on the product. Do not use aerosol sprays, solvents, abrasives, or cleaners containing hydrogen peroxide or bleach that might damage the finish.

5. Start with the display (if applicable). Wipe carefully in one direction, and move from the top of the display to the bottom. Finish with any flexible cables, like power cord, keyboard cable, and USB cables.
6. Be sure that surfaces have completely air-dried before turning the device on after cleaning.
7. Discard the gloves after each cleaning. Clean your hands immediately after you remove the gloves.

See [Cleaning your computer with a disinfectant on page 28](#) for recommended steps to clean the high-touch, external surfaces on your computer to help prevent the spread of harmful bacteria and viruses.

Cleaning your computer with a disinfectant

The World Health Organization (WHO) recommends cleaning surfaces, followed by disinfection, as a best practice for preventing the spread of viral respiratory illnesses and harmful bacteria.

After cleaning the external surfaces of your computer using the steps in [Removing dirt and debris from your computer on page 27](#), [Caring for wood veneer \(select products only\) on page 29](#), or both, you might also choose to clean the surfaces with a disinfectant. A disinfectant that is within HP's cleaning guidelines is an alcohol solution consisting of 70% isopropyl alcohol and 30% water. This solution is also known as rubbing alcohol and is sold in most stores.

Follow these steps when disinfecting high-touch, external surfaces on your computer:

1. Wear disposable gloves made of latex (or nitrile gloves, if you are latex-sensitive) when cleaning the surfaces.
2. Turn off your device and unplug the power cord and other connected external devices. Remove any installed batteries from items such as wireless keyboards.



CAUTION: To prevent electric shock or damage to components, never clean a product while it is turned on or plugged in.

3. Moisten a microfiber cloth with a mixture of 70% isopropyl alcohol and 30% water. The cloth should be moist, but not dripping wet.



CAUTION: Do not use any of the following chemicals or any solutions that contain them, including spray-based surface cleaners: bleach, peroxides (including hydrogen peroxide), acetone, ammonia, ethyl alcohol, methylene chloride, or any petroleum-based materials, such as gasoline, paint thinner, benzene, or toluene.



IMPORTANT: To avoid damaging the surface, avoid abrasive cloths, towels, and paper towels.

4. Wipe the exterior of the product gently with the moistened cloth.



IMPORTANT: Keep liquids away from the product. Avoid getting moisture in any openings. If liquid makes its way inside your HP product, it can cause damage to the product. Do not spray liquids directly on the product. Do not use aerosol sprays, solvents, abrasives, or cleaners containing hydrogen peroxide or bleach that might damage the finish.

5. Start with the display (if applicable). Wipe carefully in one direction, and move from the top of the display to the bottom. Finish with any flexible cables, like power cord, keyboard cable, and USB cables.
6. Be sure that surfaces have completely air-dried before turning the device on after cleaning.
7. Discard the gloves after each cleaning. Clean your hands immediately after you remove the gloves.

Caring for wood veneer (select products only)

Your product might feature high-quality wood veneer. As with all natural wood products, proper care is important for best results over the life of the product. Because of the nature of natural wood, you might see unique variations in the grain pattern or subtle variations in color, which are normal.

- Clean the wood with a dry, static-free microfiber cloth or chamois.
- Avoid cleaning products containing substances such as ammonia, methylene chloride, acetone, turpentine, or other petroleum-based solvents.
- Do not expose the wood to sun or moisture for long periods of time.
- If the wood becomes wet, dry it by dabbing with an absorbent, lint-free cloth.
- Avoid contact with any substance that might dye or discolor the wood.
- Avoid contact with sharp objects or rough surfaces that might scratch the wood.

See [Removing dirt and debris from your computer on page 27](#) for the recommended steps to clean the high-touch, external surfaces on your computer. After you remove the dirt and debris, you can also clean the surfaces with a disinfectant. See [Cleaning your computer with a disinfectant on page 28](#) for sanitizing guidelines to help prevent the spread of harmful bacteria and viruses.

Packaging and transporting guidelines

Follow these grounding guidelines when packaging and transporting equipment.

- To avoid hand contact, transport products in static-safe tubes, bags, or boxes.
- Protect ESD-sensitive parts and assemblies with conductive or approved containers or packaging.
- Keep ESD-sensitive parts in their containers until the parts arrive at static-free workstations.
- Place items on a grounded surface before removing items from their containers.
- Always be properly grounded when touching a component or assembly.
- Store reusable ESD-sensitive parts from assemblies in protective packaging or nonconductive foam.
- Use transporters and conveyors made of antistatic belts and roller bushings. Be sure that mechanized equipment used for moving materials is wired to ground and that proper materials are selected to avoid static charging. When grounding is not possible, use an ionizer to dissipate electric charges.

Accessing support information

Use this information to find the HP support that you need.

Table 4-3 Support information locations

Service consideration	Path to access information
Records of reported failure incidents stored on the computer	Windows: Pre-operating system failures are logged in the BIOS Event Log. To view the BIOS Event Log: 1. Press the power button. 2. Immediately and repeatedly press esc when the power button light turns white. NOTE: If you do not press esc at the appropriate time, you must restart the computer and again repeatedly press esc when the power button light turns white to access the utility. 3. Press f10 to enter the BIOS setup. 4. Complete one of these tasks: • (On commercial products) Under the Main tab, select BIOS event log, and then select View BIOS Event Log. • (On consumer products) Under the Main tab, select System Log. Post-operating system failures are logged in the Event Viewer. 1. Turn on the computer and allow the operating system to open. 2. Select the search icon  in the taskbar. 3. Type <code>Event Viewer</code>, and then press enter. 4. Select the log from the left panel. Details display in the right panel. ChromeOS™: 1. Go to support.google.com/chrome. 2. Search <code>collect Chrome device logs</code>.
Technical bulletins and alerts	To find technical bulletins, alerts, guides, and whitepapers: 1. Go to www.hp.com/support. 2. Follow the instructions to find your product. 3. Select Bulletins and Alerts to view technical bulletins.
Repair professionals	To locate repair professionals: 1. Go to www.hp.com. 2. Select Authorized service providers. 3. Select your location.
Component and diagnosis information, failure detection, and required action	To locate diagnosis information and actions: 1. Go to http://www.hp.com/go/techcenter/pcdiags. 2. Select the issue you want to diagnose.

5 Removal and replacement procedures for Customer Self-Repair parts

This chapter provides removal and replacement procedures for Customer Self-Repair parts.

 **NOTE:** The Customer Self-Repair program is not available in all locations. Installing a part that is not supported by the Customer Self-Repair program can void your warranty. Check your warranty to determine whether Customer Self-Repair is supported in your location.

 **NOTE:** The [HP Support YouTube Channel](#) (in English) has videos that provide step-by-step removal and replacement instructions for many common parts and models.

Component replacement procedures

Use these procedures to remove and replace computer components.

 **NOTE:** Details about your computer, including model, serial number, product key, and length of warranty, are on the service tag at the bottom of your computer.

 **NOTE:** HP continually improves and changes product parts. For complete and current information about supported parts for your computer, go to <https://partsurfer.hp.com/>, select your country or region, and then follow the on-screen instructions.

Make special note of each screw size and location during removal and replacement.

Preparation for disassembly

Use these procedures to remove and replace computer components.

For initial safety procedures, see [Removal and replacement procedures preliminary requirements on page 23](#).

1. Turn off the computer. If you are unsure whether the computer is off or in hibernation or sleep mode, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.

Bottom cover

Use these procedures and illustrations to remove the bottom cover.

Table 5-1 Bottom cover description and part number

Description	Spare part number
Bottom cover, atmospheric blue models	P92682-001
Bottom cover, eclipse gray models	P92681-001
Bottom cover, meteor silver models	P92898-001


Before removing the bottom cover, prepare the computer for disassembly (see [Preparation for disassembly on page 31](#)).

Remove the bottom cover:


1. Remove the three Phillips M2.0 × 3.0 screws that secure the bottom cover to the computer (1).
2. Loosen the Phillips M2.0 × 6.0 captive screw that secures the bottom cover to the computer (2).



NOTE: The bottom cover includes a captive (not removable) screw that causes the cover to pop up when you loosen the screw. **After the cover pops up, do not continue to loosen the captive screw.**



3. Use a nonmarking, nonconductive tool (1) to release the edges of the bottom cover from the computer.
4. Remove the bottom cover (2) from the computer.



Reverse the removal procedures to replace the bottom cover.


When replacing the bottom cover, remove the Feature Byte label from the inside of the old bottom cover and place it on the inside of the new bottom cover. Be sure to keep this label with the computer, because the label is required for any future repairs.

You can locate product labels:

- Laser etched on the old bottom cover.
- In HP System Information by pressing **fn + esc** when you turn on the computer.




NOTE: Bottom cover appearance might vary.




Hand write the product information onto the label of the new bottom cover. Use a ballpoint pen or marker to avoid smudging.

Example of label information



New bottom cover label location



Battery

The battery removal procedure differs depending on whether you are removing and replacing the existing battery or installing a new battery. To install a new battery, you must use a revive kit.

- To remove and replace the existing battery, see [Removing and reinstalling the same battery on page 34](#).
- To install a new battery, see [Installing a new battery on page 35](#).

Removing and reinstalling the same battery

Use this procedure and illustration to remove the battery.

⚠ WARNING! To avoid personal injury and damage to the product:

- Do *not* puncture, twist, or crack the battery.
- Do *not* cause an external puncture or rupture to the battery, which can cause a short inside the battery that can result in battery thermal runaway.
- Do *not* handle or touch the battery enclosure with sharp objects such as tweezers or pliers, which might puncture the battery.
- Do *not* compress or squeeze the battery case with tools or heavy objects stacked on top of the case. These actions can apply undue force on the battery.
- Do *not* touch the connectors with any metallic surface or object, such as metal tools, screws, or coins, which can cause shorting across the connectors.

For additional battery information, see the *Regulatory, Safety, and Environmental Notices*. To access this guide, select the **Search** icon in the taskbar, type `HP Documentation` in the search box, and then select **HP Documentation**.

Before removing the battery, follow these steps:


1. Prepare the computer for disassembly (see [Preparation for disassembly on page 31](#)).
2. Remove the bottom cover (see [Bottom cover on page 31](#)).

⚠ WARNING! To reduce potential safety issues, use only the user-replaceable battery provided with the computer, a replacement battery provided by HP, or a compatible battery purchased from HP.

📝 IMPORTANT: Removing a battery that is the sole power source for the computer can cause loss of information. To prevent loss of information, save your work or shut down the computer through Windows before you remove the battery.

Remove the battery:

1. Disconnect the battery cable (1) from the system board.
2. Remove the five Phillips M2.0 × 4.0 screws (2) that secure the battery to the computer.
3. Remove the battery from the computer (3).



Reverse this procedure to install the battery.

📝 NOTE: When reinstalling the battery, be sure to completely reassemble the computer and plug in the AC adapter before turning the computer on.

Installing a new battery

Use these procedures and illustrations to install the battery. You must use a revive kit to remove the old battery and install a new one. The revive kit includes an empty containment tray and a containment tray with a battery preinstalled.

Table 5-2 Battery description and part number

Description	Spare part number
Battery, 4 cell, 78 Whr (includes revive kit)	P55091-001
Battery, 4 cell, 70 Whr (includes revive kit)	P55092-001

Table 5-2 Battery description and part number (continued)

Description	Spare part number
Battery cable (available in the Cable Kit)	P92665-001

Before starting this replacement procedure:

- Ensure other individuals are sufficiently clear of your workspace.
- Ensure your workspace is clear of any flammable material such as paper or oils.
- Locate the nearest ABC dry chemical fire extinguisher for use in an emergency.

 **WARNING!** This procedure requires removing the battery or disconnecting the battery cable. Use care to avoid bending, twisting, or puncturing the battery regardless of its condition. Failure to follow this replacement guide or to use HP recommended tools might damage the system and/or cause a safety hazard.

- Do *not* remove the battery from the containment tray.
- Do *not* handle or touch the battery enclosure with sharp objects such as tweezers or pliers, which might puncture the battery.
- Do *not* touch the connectors with any metallic surface or object, such as metal tools, screws, or coins, which can cause shorting across the connectors.

Should a part become stuck or difficult to remove when opening a unit where a swollen battery is suspected, or if the battery becomes stuck in the unit, stop and contact HP Support for assistance. Do not try to remove a battery by force.

 **NOTE:** Screw locations, latch locations, and internal components might vary.

Before removing the battery, follow these steps:


1. Prepare the computer for disassembly (see [Preparation for disassembly on page 31](#)).
2. Remove the bottom cover (see [Bottom cover on page 31](#)).

 **WARNING!** To reduce potential safety issues, use only the user-replaceable battery provided with the computer, a replacement battery provided by HP, or a compatible battery purchased from HP.

 **IMPORTANT:** Removing a battery that is the sole power source for the computer can cause loss of information. To prevent loss of information, save your work or shut down the computer through Windows before you remove the battery.

1. Remove the battery using the revive kit:


- a. Disconnect the battery cable from the system board. The connector location might vary.



- b. Open the empty battery containment tray.




- c. Remove the paper backing layer from the adhesive on the tray.




- d. Turn the tray (1) over so that the adhesive is facing down.
- e. Place the tray (2) centered on the battery.


- f. Press down on the indentations on the tray (3) to adhere it to the battery.



- g. Remove the Phillips screws (1) that secure the battery to the computer. Number of screws and screw locations might vary.
- h. Lift the top of the tray (2) to remove the battery from the computer.




- i. Rotate the battery up and over into the cavity of the containment tray.




 **NOTE:** Please recycle responsibly. For more information about recycling programs, see the HP website at <http://www.hp.com/recycle>.

2. Install the battery using the revive kit:
 - a. Open the containment tray that includes the new battery.
 - b. Turn the tray (1) over so the battery is facing downward, and then insert the battery (2) into the computer. Adhesive secures the battery to the tray.




- c. Install the Phillips screws (1) to secure the battery. Number of screws and screw locations might vary.

- d. Lift the containment tray (2) off the battery.



- e. Connect the battery cable to the system board. The connector location might vary.



NOTE: When replacing the battery, be sure to completely reassemble the computer and plug in the AC adapter before turning the computer on.

6 Removal and replacement procedures for authorized service provider parts

This chapter provides removal and replacement procedures for authorized service provider parts.

 **IMPORTANT:** Only an authorized service provider should access the components described in this chapter. Accessing these parts can damage the computer or void the warranty.

 **NOTE:** Details about your computer, including model, serial number, product key, and length of warranty, are on the service tag at the bottom of your computer.

 **NOTE:** The [HP Support YouTube Channel](#) (in English) has videos that provide step-by-step removal and replacement instructions for many common parts and models.

Component replacement procedures

Use the procedures described in this section to remove and replace computer components.

 **NOTE:** HP continually improves and changes product parts. For complete and current information about supported parts for your computer, go to <https://partsurfer.hp.com/>, select your country or region, and then follow the on-screen instructions.

Make special note of each screw size and location during removal and replacement.

Solid-state drive

Use this procedure and illustration to remove the solid-state drive (SSD).

Table 6-1 SSD descriptions and part numbers

Description	Spare part number
2 TB	P07215-005
	P73031-005
1 TB	N77394-005
	P73030-005
512 GB	N77392-005
	P73029-005

Before removing the SSD, follow these steps:


1. Prepare the computer for disassembly (see [Preparation for disassembly on page 31](#)).
2. Remove the bottom cover (see [Bottom cover on page 31](#)).
3. Disconnect the battery cable from the system board (see [Battery on page 34](#)).

Remove the SSD:




NOTE: Actual computer features, feature locations, icon labels, and accessories might vary from images depicted.

1. Remove the two Phillips M2.0 × 2.5 screws (1) that secure the shield to the drive and then remove the shield (2).




2. Lift and pull the drive away from the socket to remove it.



Reverse this procedure to install the SSD.

When installing an SSD, be sure a thermal pad is installed on the bottom of the SSD cover.



NOTE: SSDs are designed with a notch to prevent incorrect insertion.

Speakers

Use this procedure and illustration to remove the speakers.

Table 6-2 Speaker description and part number

Description	Spare part number
Speakers (left and right)	P92685-001

Before removing the speakers, follow these steps:


1. Prepare the computer for disassembly (see [Preparation for disassembly on page 31](#)).
2. Remove the bottom cover (see [Bottom cover on page 31](#)).
3. Disconnect the battery cable from the system board (see [Battery on page 34](#)).

Remove the speakers:

NOTE: Actual computer features, feature locations, icon labels, and accessories might vary from images depicted.

1. Disconnect the speaker cable **(1)** from the system board.
2. Remove the four Phillips M2.0 × 4.0 screws **(2)** that secure each speaker to the computer.
3. Remove the right speaker **(3)**.
4. Remove the speaker cable **(4)** from the touchpad bracket.

5. Remove the left speaker (5) from the computer.



Reverse this procedure to install the speakers.

Fan

Use this procedure and illustration to remove the fan.

Table 6-3 Fan description and part number

Description	Spare part number
Fan assembly	P92683-001

Before removing the fan, follow these steps:


1. Prepare the computer for disassembly (see [Preparation for disassembly on page 31](#)).
2. Remove the bottom cover (see [Bottom cover on page 31](#)).
3. Disconnect the battery cable from the system board (see [Battery on page 34](#)).

Remove the fan assembly:


 **NOTE:** Actual computer features, feature locations, icon labels, and accessories might vary from images depicted.

1. Disconnect the camera cable from the ZIF connector on the system board (1).
2. Remove the transparent antenna cover (2) from the WLAN module, and then disconnect the antenna cables from the module (3).

3. Lift and unroute the camera cable and the antenna cables from the clips around the fan (4) to clear the area.



4. Disconnect the fan cable (1) from the i/o board.
5. Lift and unroute the camera cable from the retention clips (2), remove the three Phillips M2.0 × 5.0 screws that secure the fan to the computer (3), and then remove the fan (4) from the computer.



Reverse this procedure to install the fan.

I/O board

Use this procedure and illustration to remove the I/O board.

Table 6-4 I/O board description and part number

Description	Spare part number
I/O board (includes cable)	
Intel model	P96561-001
AMD model	P92675-001

Before removing the I/O board, follow these steps:


1. Prepare the computer for disassembly (see [Preparation for disassembly on page 31](#)).
2. Remove the bottom cover (see [Bottom cover on page 31](#)).
3. Disconnect the battery cable from the system board (see [Battery on page 34](#)).

Remove the I/O board:

1. Lift but don't remove the tape from the I/O board cable (1).
2. Disconnect the cable from the system board ZIF connector (2).
3. Disconnect the fan cable from the I/O board (3).
4. Remove the two Phillips M2.0 × 3.0 screws (4) that connect the FPC cable from the I/O board to the system board.
5. Remove the three Phillips M2.0 × 3.0 screws (5) that secure the I/O board.
6. Remove the I/O board (6) from the computer.



NOTE: Retain the metal piece that rests on the Type-C port if needed for reinstall purposes.



Reverse this procedure to install the USB board.

WLAN module

Use this procedure and illustration to install the WLAN module.

Table 6-5 WLAN module descriptions and part numbers

Description	Spare part number
MediaTek MT7925 Wi-Fi 7 Bluetooth 5.43	N64647-005
Intel Wi-Fi 7 BE211 Bluetooth 6	P36621-005
Realtek Chivas M.2 2230 Wi-Fi 7 +Bluetooth 6.0	P44408-005

 **IMPORTANT:** To prevent an unresponsive system, replace the wireless module only with a wireless module authorized for use in the computer by the governmental agency that regulates wireless devices in your country or region. If you replace the module and then receive a warning message, remove the module to restore device functionality, and then contact technical support.


Before removing the WLAN module, follow these steps:

1. Prepare the computer for disassembly (see [Preparation for disassembly on page 31](#)).
2. Remove the bottom cover (see [Bottom cover on page 31](#)).
3. Disconnect the battery cable from the system board (see [Battery on page 34](#)).


Remove the WLAN module:

1. Remove the antenna protector **(1)** from the module.
2. Carefully disconnect the two antenna cables **(2)** from the module.
3. Remove the Phillips M2.0 × 2.5 screw **(3)**, and then remove the WLAN module **(4)**.


 **NOTE:** Models have either one or two WLAN antennas. On models with two antennas, the #1 white WLAN antenna cable connects to the WLAN module #1 Main terminal. The #2 black WLAN antenna cable connects to the WLAN module #1 Aux terminal.



4. If the WLAN antenna is not connected to the terminal on the WLAN module, install a protective sleeve on the antenna connector, as shown in the following illustration.



When installing a WLAN module, be sure that a thermal pad is installed on the bottom of the module.



Reverse this procedure to install the WLAN module.

Touchpad

Use this procedure and illustration to remove the touchpad.

Table 6-6 Touchpad description and part number

Description	Spare part number
Touchpad (includes cable)	
Atmospheric blue models	P92679-001
Eclipse gray models	P92678-001
Meteor silver models	P92879-001


Before removing the touchpad, follow these steps:

1. Prepare the computer for disassembly (see [Preparation for disassembly on page 31](#)).
2. Remove the bottom cover (see [Bottom cover on page 31](#)).
3. Remove the battery (see [Battery on page 34](#)).


Remove the touchpad:

1. Remove the four Phillips M2.0 × 3.0 screws **(1)** that secure the touchpad bracket to the computer.
2. Lift the speaker cable **(2)** up enough to remove the bracket.

3. Remove the touchpad bracket from the computer (3).



4. Disconnect the cable from the ZIF connector (1) on the touchpad.
5. Remove the three Phillips M2.0 × 3.0 screws (2) that secure the touchpad to the computer.
6. Remove the touchpad (3) from the computer.



Reverse this procedure to install the touchpad.

System board

Use these procedures and illustrations to remove the system board.

Table 6-7 System board descriptions and part numbers

Description	Spare part number
System board (includes processor):	
System board (includes processor; for use in models with an AMD processor.)	
AMD Ryzen AI 5 430 processor, 16 GB system memory	P92885-601
AMD Ryzen AI 5 435 processor, 16 GB system memory	P92886-601
AMD Ryzen AI 7 450 processor, 32 GB system memory	P92887-601
AMD Ryzen AI 9 465 processor, 32 GB system memory	P92888-601
AMD Ryzen AI 7 445 processor, 32 GB system memory	P92889-601
AMD Ryzen AI 7 445 processor, 16 GB system memory	Q03247-601
AMD Ryzen AI 7 450 processor, 24 GB system memory	Q06474-601
AMD Ryzen AI 5 435 processor, 24 GB system memory	Q06476-601
AMD Ryzen AI 7 445 processor, 24 GB system memory	Q06477-601
AMD Ryzen AI 5 430 processor, 16 GB system memory	P92885-601
AMD Ryzen AI 5 435 processor, 16 GB system memory	P92886-601
System board (includes processor; for use in models with an Intel processor).	
Intel Core Ultra 9 386H processor, 32 GB system memory	P92652-601
Intel Core Ultra 7 356H processor, 32 GB, system memory	P92651-601
Intel Core Ultra 7 355 processor, 16 GB system memory	P92649-601
Intel Core Ultra 7 355 processor, 32 GB system memory	P92657-601
Intel Core Ultra 7 355 processor, 32 GB system memory	Q06468-601
Intel Core Ultra 5 325 processor, 24 GB system memory	Q06467-601
Intel Core Ultra 7 355 processor, 24 GB system memory	Q06478-601
Intel Core Ultra 7 355 processor, 24 GB system memory	Q06479-601
System board (includes processor; for use in models with the Windows operating system in the PRC),	
Intel Core Ultra 9 386H processor, 32 GB system memory	P92656-601
Intel Core Ultra 7 356H processor, 32 GB system memory	P92655-601
Intel Core Ultra 7 355 processor, 32 GB system memory	P92658-601
Intel Core Ultra 7 355 processor, 16 GB system memory	P92654-601
Intel Core Ultra 5 325 processor, 24 GB system memory	Q06480-601
Intel Core Ultra 7 355 processor, 24 GB system memory	Q06481-601
Intel Core Ultra 5 325 processor, 16 GB system memory	P92653-601

Before removing the system board, follow these steps:

1. Prepare the computer for disassembly (see [Preparation for disassembly on page 31](#)).
2. Remove the bottom cover (see [Bottom cover on page 31](#)).

3. Remove the battery (see [Battery on page 34](#)).
4. Remove the solid-state drive (see [Solid-state drive on page 41](#)).
5. Remove the WLAN module (see [WLAN module on page 47](#)).
6. Remove the fan assembly (see [Fan on page 44](#)).
7. Remove the heat sink (see [Heat sink on page 53](#)).


Remove the system board:




NOTE: Actual computer features, feature locations, icon labels, and accessories might vary from images depicted.

1. Disconnect the following cables from the system board:


- Display cable (ZIF) (1)
- IR board cable (ZIF)(2)
- Speaker cable (3)
- Touchpad cable (ZIF) (4)
- Keyboard cable (ZIF) (5)
- Keyboard backlight cable (ZIF) (6)
- Camera cable (ZIF) (7)
- I/O board cable (ZIF) (8)
- Flexible printed circuit (FPC) cable (ZIF) (9)



2. Remove the Phillips M2.0 × 5.0 screw **(1)** and the three Phillips M2.0 × 5.0 screws **(2)** that secure the system board to the computer.



3. Lift the system board away from the heat sink connector **(1)** and then pull up and to the left **(2)** to remove it. The USB bracket **(3)** comes loose after you remove the system board.



Reverse this procedure to install the system board.

Heat sink

Use these procedures and illustrations to remove the heat sink.

Table 6-8 Heat sink descriptions and part numbers


Description	Spare part number
Heat sink	
AMD models	P92899-001
Intel models	P92684-001

Before removing the heat sink, follow these steps:

1. Prepare the computer for disassembly (see [Preparation for disassembly on page 31](#)).
2. Remove the bottom cover (see [Bottom cover on page 31](#)).
3. Disconnect the battery cable from the system board (see [Battery on page 34](#)).
4. Remove the fan assembly (see [Fan on page 44](#)).
5. Remove the system board (see [System board on page 50](#)).


Remove the heat sink:

1. In the order indicated on the heat sink, remove the four Phillips M2.0 × 4.0 screws **(1)** that secure the heat sink to the system board.
2. Remove the heat sink **(2)** from the system board.



3. Thoroughly clean the thermal material from the surfaces of the heat sink and the system board components each time the heat sink is removed. Replacement thermal material is included with the heat sink and system board spare part kits. The following illustration shows the replacement thermal material locations.

Thermal paste is used on the system board components and on the heat sink areas **(1)**, **(2)** that service them.



Reverse this procedure to install the heat sink.

Infrared (IR) sensor board

To remove the IR sensor board, use this procedure and illustration.

Table 6-9 IR sensor board description and part number

Description	Spare part number
IR sensor board (includes cable)	
AMD model	P96560-001
Intel model	P92674-001


Before removing the IR sensor board, follow these steps:

1. Prepare the computer for disassembly (see [Preparation for disassembly on page 31](#)).
2. Remove the bottom cover (see [Bottom cover on page 31](#)).
3. Remove the battery (see [Removing and reinstalling the same battery on page 34](#)).
4. Remove the system board (see System board.)

Remove the IR sensor board:

1. Remove any tape that covers the IR sensor board connector.
2. Disconnect the cable from the ZIF connector (1) on the IR sensor board.

3. Remove the Phillips M2.0 × 5.0 screw (2) that secures the IR sensor board to the computer, and then remove the board (3).



Reverse this procedure to install the IR sensor board.

Display assembly

Use these procedures and illustrations to remove and disassemble the display assembly.

Full hinge-up displays are not available as spare parts. Spare parts for displays are available only at the subcomponent level.

Before removing the display panel, follow these steps:

1. Prepare the computer for disassembly (see [Preparation for disassembly on page 31](#)).
2. Remove the bottom cover (see [Bottom cover on page 31](#)).
3. Remove the battery (see [Battery on page 34](#)).


Remove the display assembly:




NOTE: Actual computer features, feature locations, icon labels, and accessories might vary from images depicted.

1. Lift the tape (1) off the display connector on the system board and then remove the display cable from the clip (2) at the top of the computer next to the hinge.
2. Disconnect the antenna cables from the WLAN module (3).
3. Disconnect the camera cable from the ZIF connector (4) on the system board.

4. Remove the antenna cables and camera cable from the clips (5) around the fan up to the clip at the top of the computer next to the hinge.




5. Remove the eight Phillips M2.5 × 5.0 screws that secure the display assembly to the computer.




6. Rotate the display (1) upward to open the hinges.

7. Separate the display assembly (2) from the computer.




8. To remove the display panel:

- a. Detach the display panel by releasing the hooks on the top edge of the display, and then lifting the panel (1) so you can grasp the ends of the stretchable tape installed on both sides of the display.
- b. Use a hook turner (1.1 mm - 1.2 mm) (2) to grasp the hole in the tape, and then pull the tape (3) out from both sides of the panel.




- c. If you would like to create a substitute for a hook turner, you can bend the end of a plastic paper clip to create a hook from 1.1 mm - 1.2 mm wide.




- d. Use a tool to separate the top (1), bottom of left and right sides (2), and bottom (3) of the panel from the display rear cover, and then remove the rear cover (4).


Display panels are available as spare part number P92660-001 for 2.8K OLED models, P92661-001 for WUOLED models, P92660-001 for WUXGA LED models.



- e. When installing a display panel, use the following illustration to determine tape installation locations on the inside of the display rear cover.




- f. (OLED panels only) When installing a display panel, be sure thermal pads and graphite sheets are installed on the inside of the display rear cover in the locations shown in the following illustration.




- 9. To remove the touch control board:

- a. (OLED models only) Peel the foil up off the bottom of the display to access the components underneath.



- b. Peel the tape covering the cable (1).
- c. Disconnect the cable from the small ZIF connector (2) on the touch board.
- d. Disconnect the cable from the two wide reverse ZIF connectors (3) on the touch board.
- e. Pull the stretchable tape (4) out from behind the board.
- f. Remove the thin tape (5) that secures the board to the panel.
- g. Remove the touch control board (6).


The touch control board with included cable is available as spare part number P92676-001.




- 10. To remove the OLED board:
 - a. Disconnect the cable from the ZIF connector (1) on the board.

- b. Remove the black tape (2) from the board.
- c. Pull the stretchable tape (3) out from behind the board.
- d. Remove the OLED board (4).

The OLED control board with included cable is available as spare part number P92677-001.




- e. When installing an OLED board, be sure that a thermal pad is installed on the board.




11. To remove the display cable:

- a. **OLED models:** Peel the conductive tape (1) and clear tape (2) off the connector on the bottom of the panel.
- b. Open the locking bar (3), and then disconnect the cable (4) from the panel.

Display cables are available as spare part number P29028-001.




- c. Disconnect the cable from the ZIF connector (1) on the OLED board.
- d. Disconnect the cable from the ZIF connector (2) on the touch board.
- e. Remove the cable (3) from the panel.




- f. **LED models:** Peel the conductive tape (1) and clear tape (2) off the connector on the bottom of the panel.

- g. Open the locking bar (3), and then disconnect the cable (4) from the panel.




- h. Disconnect the cable from the ZIF connector (1) on the OLED board.
- i. Remove the cable (2) from the panel.




12. To remove the camera module:

- a. Disconnect the cable from the ZIF connector (1) on the camera module.
- b. Starting on the right side, insert a pry tool (2) under the camera module, and then pull the tool to the left (3) to release the module.

The camera module is available as spare part number P92680-001.




- c. On OLED models, when installing a camera module, be sure to install the camera foil (1) and sponge (2) onto the display rear cover under the camera module.




13. To remove the hinges and hinge covers from the display rear cover:
 - a. Remove the three Phillips M2.0 × 2.5 screws (1) from each hinge.
 - b. Remove the hinges (2) from the display back cover.

The display hinges are available as spare part number P92671-001.



- c. Remove the Phillips M1.6 × 2.5 screw **(1)** from each hinge.
- d. Pull the covers **(2)** off the hinges.


The display hinge covers are available as spare part number P29050-001.



- 14. To remove the wireless antennas and cables:
 - a. Lift the foil **(1)** off the cables.
 - b. Remove the antenna cables **(2)** from the left hinge.
 - c. Lift the tape **(3)** that secures the cables to the display rear cover.
 - d. Remove the cables from the routing paths and clips **(4)** in the display rear cover.

- e. Peel the antennas **(5)** off the display rear cover.


The wireless cables and antennas are available in the Cable Kit as spare part number P92665-001. The wireless cables and antennas are also included in the display rear cover spare part kit.



15. To remove the camera cable:

- a. Disconnect the cable from the ZIF connector **(1)** on the camera module.
- b. Peel the cable **(2)** off the inside of the display rear cover.
- c. Lift the tape **(3)** that secures the cable to the display rear cover.
- d. Remove the cable **(4)** from the right hinge.

The camera cable is available in the Cable Kit as spare part number P92665-001.



To reassemble and replace the display assembly, reverse these procedures.

Keyboard with top cover

The top cover with keyboard remains after removing all other spare parts from the computer. In this section, the first table provides the main spare part numbers for the top cover with keyboards. The second table provides the country codes.

Table 6-10 Keyboard with top cover descriptions and part numbers

Description	Spare part number
Keyboard with top cover, atmospheric blue with image sensor backlight keyboard	P92662-001
Keyboard with top cover, eclipse gray with image sensor backlight keyboard	P92663-001
Keyboard with top cover, darker meteor silver with image sensor backlight keyboard	P92893-001

Table 6-11 Spare part country codes

For use in country or region	Spare part number	For use in country or region	Spare part number	For use in country or region	Spare part number
Belgium	-A41	Iceland	-DD1	Saudi Arabia	-171
Brazil	-201	India	-D61	Slovenia	-BA1
Bulgaria	-261	Israel	-BB1	South Korea	-AD1
Chile	-161	Italy	-061	Spain	-071
Czech Republic/Slovakia	-FL1	Japan	-291	Switzerland	-BG1
Denmark, Finland, and Norway	-DH1	Kazakhstan	-DF1	Taiwan	-AB1
French Canada	-DB1	The Netherlands	-B31	Thailand	-281
France	-051	Northern Africa	-FP1	Turkey	-141

Table 6-11 Spare part country codes (continued)

For use in country or region	Spare part number	For use in country or region	Spare part number	For use in country or region	Spare part number
Germany	-041	Portugal	-131	Ukraine	-BD1
Greece	-151	Romania	-271	United Kingdom	-031
Hungary	-211	Russia	-251	United States	-001

7 Backing up, restoring, and recovering

You can use Windows tools or HP software to back up your information, create a restore point, reset your computer, create recovery media, or restore your computer to its factory state. Performing these standard procedures can return your computer to a working state faster.

 **IMPORTANT:** If you are performing recovery procedures on a tablet, the tablet battery must be at least 70% charged before you start the recovery process.

 **IMPORTANT:** For a tablet with a detachable keyboard, connect the tablet to the keyboard base before beginning any recovery process.

Backing up information and creating recovery media

These methods of creating recovery media and backups are available on select products only.

Using Windows tools for backing up

HP recommends that you back up your information immediately after initial setup. You can do this task either using Windows Backup locally with an external USB flash drive or using online tools.

 **NOTE:** If computer storage is 32 GB or less, Microsoft System Restore is disabled by default.

Using the HP Cloud Recovery Download Tool to create a recovery USB flash drive (select products only)

You can use the HP Cloud Recovery Download Tool to create an HP Recovery bootable USB flash drive.

For details:

- Go to <http://www.hp.com>, search for HP Cloud Recovery, and then select the result that matches the type of computer that you have and follow the on-screen instructions.

 **NOTE:** In select countries, if you cannot create the HP Recovery USB flash drive yourself, contact support. Go to <http://www.hp.com/support>, select your country or region, and then follow the on-screen instructions.

 **IMPORTANT:** HP recommends that you follow the [Restoring and recovery methods on page 71](#) to restore your computer before you obtain and use the HP USB flash drive. Using a recent backup can return your machine to a working state sooner than using the HP USB flash drive. After the system is restored, reinstalling all the operating system software released since your initial purchase can be a lengthy process.

Restoring and recovering your system

You have several tools available to recover your system both within and outside of Windows if the desktop cannot load.

HP recommends that you attempt to restore your system using the [Restoring and recovery methods on page 71](#).

Creating a system restore

System Restore is available in Windows. The System Restore software can automatically or manually create restore points, or snapshots, of the system files and settings on the computer at a particular point.

When you use System Restore, it returns your computer to its state at the time you made the restore point. Your personal files and documents should not be affected.

Restoring and recovery methods

After you run the first method, test to see whether the issue still exists before you proceed to the next method, which might now be unnecessary.

1. Run a Microsoft System Restore.
2. Run Reset this PC.



NOTE: The options **Remove everything** and then **Fully clean the drive** can take several hours to complete and leave no information on your computer. It is the safest way to reset your computer before you recycle it.

3. Recover using the HP Recovery USB flash drive. For more information, see [Recovering using the HP Recovery USB flash drive on page 71](#).

For more information about the first two methods, see the Get Help app:

- Select the **Start** button, select **All apps**, select the **Get Help** app, and then enter the task you want to perform.



NOTE: You must be connected to the internet to access the Get Help app.

Recovering using the HP Recovery USB flash drive

You can use the HP Recovery USB flash drive to recover the operating system and drivers that were installed at the factory. On select products, you can create recovery media on a bootable USB flash drive using the HP Cloud Recovery Download Tool.

For details, see [Using the HP Cloud Recovery Download Tool to create a recovery USB flash drive \(select products only\) on page 70](#).



NOTE: In select countries, if you cannot create the HP Recovery USB flash drive yourself, contact support. Go to <http://www.hp.com/support>, select your country or region, and then follow the on-screen instructions.

To recover your system:

- Insert the HP Recovery USB flash drive, and then restart the computer.



NOTE: HP recommends that you follow the [Restoring and recovery methods on page 71](#) to restore your computer before you obtain and use the HP USB flash drive. Using a recent backup can return your machine to a working state sooner than using the HP USB flash drive. After the system is restored, reinstalling all the operating system software released since your initial purchase can be a lengthy process.

Changing the computer boot order

If your computer does not restart using the HP Recovery USB flash drive, you can change the computer boot order, which is the order of devices listed in BIOS for startup information.



IMPORTANT: For a tablet with a detachable keyboard, connect the tablet to the keyboard base before beginning these steps.

To change the boot order:

1. Insert the HP Recovery USB flash drive.
2. Access the system **Startup** menu.
 - For computers or tablets with keyboards attached, turn on or restart the computer or tablet, quickly press **esc**, and then press **f9** for boot options.
 - For tablets without keyboards, turn on or restart the tablet, and then quickly press and hold one of the following buttons:
 - Volume up
 - Volume down

Then select **f9**.
3. Select the USB flash drive to boot from, and then follow the on-screen instructions.

Using HP Sure Recover (select products only)

Select computer models are configured with HP Sure Recover, a PC operating system (OS) recovery solution built into the hardware and software. HP Sure Recover can fully restore the HP OS image without installed recovery software.

Using HP Sure Recover, an administrator or user can restore the system and install:

- Latest version of the OS
- Platform-specific device drivers
- Software applications, in the case of a custom image

To access the latest documentation for HP Sure Recover, go to <http://www.hp.com/support>. Follow the on-screen instructions to find your product and locate your documentation.

8 Using Setup Utility (BIOS)

Setup Utility, or Basic Input/Output System (BIOS), controls communication between all the input and output devices on the system (such as disk drives, display, keyboard, mouse, and printer). Setup Utility (BIOS) includes settings for the types of devices installed, the startup sequence of the computer, and the amount of system and extended memory.



NOTE: To start Setup Utility on convertible computers, your computer must be in notebook mode and you must use the keyboard attached to your notebook.

Starting Setup Utility (BIOS)

You have several ways to access the Setup Utility (BIOS).



IMPORTANT: Use extreme care when making changes in Setup Utility (BIOS). Errors can prevent the computer from operating properly.

Use one of these options:

- Turn on or restart the computer and quickly press **F10**.
- Turn on or restart the computer, quickly press **Esc**, and then press **F10** when the Start menu is displayed.

Updating Setup Utility (BIOS)

Updated versions of Setup Utility (BIOS) might be available on the HP website. Most BIOS updates on the HP website are packaged in compressed files called *SoftPaqs*. Some download packages contain a file named `Readme.txt`, which contains information regarding installing and troubleshooting the file.

Determining the BIOS version

To decide whether you need to update Setup Utility (BIOS), first determine the BIOS version on your computer.

To reveal the BIOS version information (also known as *ROM date* and *System BIOS*), use one of these options.

- HP Support Assistant
 1. Perform one of these tasks:
 - Select the **Search** icon in the taskbar, type `support` in the search box, and then select the **HP Support Assistant** app.
 - Select the question mark icon in the taskbar.
 2. Under **My notebook**, select **Specifications**.
- Setup Utility (BIOS)

1. Start Setup Utility (BIOS) (see [Starting Setup Utility \(BIOS\) on page 73](#)).
 2. Select **Main**, and then make note of the BIOS version.
 3. Select **Exit**, select one of the options, and then follow the on-screen instructions.
- In Windows, press **ctrl+alt+s**.

To check for later BIOS versions, see [{Xref Error! Target does not exist.}](#).

Preparing for a BIOS update

Be sure to follow all prerequisites before downloading and installing a BIOS update.



IMPORTANT: To reduce the risk of damage to the computer or an unsuccessful installation, download and install a BIOS update only when the computer is connected to reliable external power using the HP AC adapter provided with the computer (select products only), a replacement AC adapter provided by HP, or an AC adapter with the power rating specified on the product label. Do not download or install a BIOS update while the computer is running on battery power, docked in an optional docking device, or connected to an optional power source. During the download and installation, follow these instructions:

- Do not disconnect power from the computer by unplugging the power cord from the AC outlet.
- Do not shut down the computer or initiate sleep.
- Do not insert, remove, connect, or disconnect any device, cable, or cord.



NOTE: If your computer is connected to a network, consult the network administrator before installing any software updates, especially system BIOS updates.

Downloading a BIOS update

After you review the prerequisites, you can check for and download BIOS updates.

1. Perform one of these tasks:
 - Select the **Search** icon in the taskbar, type `support` in the search box, and then select the **HP Support Assistant** app.
 - Select the question mark icon in the taskbar.
2. Select **Updates**. The **Checking for Updates** window opens, and Windows checks for updates.
3. Follow the on-screen instructions.
4. At the download area, follow these steps:
 - a. Identify the most recent BIOS update and compare it to the BIOS version currently installed on your computer. If the update is more recent than your BIOS version, make a note of the date, name, or other identifier. You might need this information to locate the update later, after it has been downloaded to your hard drive.
 - b. Follow the on-screen instructions to download your selection to the hard drive.

Make a note of the path to the location on your hard drive where the BIOS update is downloaded. You will need to access this path when you are ready to install the update.

Installing a BIOS update

BIOS installation procedures vary. Follow any instructions that appear on the screen after the download is complete. If no instructions appear, follow these steps.

1. Select the **Search** icon in the taskbar, type `file` in the search box, and then select **File Explorer**.
2. Select your hard drive designation. The hard drive designation is typically Local Disk (C:).
3. Using the hard drive path you recorded earlier, open the folder that contains the update.
4. Double-click the file that has an .exe extension (for example, *filename.exe*).

The BIOS installation begins.

5. Complete the installation by following the on-screen instructions.



NOTE: After a message on the screen reports a successful installation, you can delete the downloaded file from your hard drive.

9 Using HP PC Hardware Diagnostics

You can use the HP PC Hardware Diagnostics utility to determine whether your computer hardware is running properly. The three versions are HP PC Hardware Diagnostics Windows, HP PC Hardware Diagnostics UEFI (Unified Extensible Firmware Interface), and (for select products only) Remote HP PC Hardware Diagnostics UEFI, a firmware feature.

Using HP PC Hardware Diagnostics Windows (select products only)

HP PC Hardware Diagnostics Windows is a Windows-based utility that allows you to run diagnostic tests to determine whether the computer hardware is functioning properly. The tool runs within the Windows operating system to diagnose hardware failures.

If HP PC Hardware Diagnostics Windows is not installed on your computer, you must download and install it. To download HP PC Hardware Diagnostics Windows, see [Downloading HP PC Hardware Diagnostics Windows on page 77](#).

Using an HP PC Hardware Diagnostics Windows hardware failure ID code

When HP PC Hardware Diagnostics Windows detects a failure that requires hardware replacement, a 24-digit failure ID code is generated for select component tests. For interactive tests, such as keyboard, mouse, or audio and video palette, you must perform troubleshooting steps before you can receive a failure ID.

You have several options after you receive a failure ID:

- Select **Next** to open the Event Automation Service (EAS) page, where you can log the case.
- Scan the QR code with your mobile device, which takes you to the EAS page, where you can log the case.
- Select the box next to the 24-digit failure ID to copy your failure code and send it to support.

Accessing HP PC Hardware Diagnostics Windows

After HP PC Hardware Diagnostics Windows is installed, you can access it from HP Support Assistant or the Start menu.

Accessing HP PC Hardware Diagnostics Windows from HP Support Assistant (select products only)

After HP PC Hardware Diagnostics Windows is installed, follow these steps to access it from HP Support Assistant.

1. Complete one of the following tasks:
 - Select the **Search** icon in the taskbar, type `support` in the search box, and then select the **HP Support Assistant** app.
 - Select the question mark icon in the taskbar.

2. Select **Fixes & Diagnostics**.
3. Select **Run hardware diagnostics**, and then select **Launch**.
4. When the tool opens, select the type of diagnostic test that you want to run, and then follow the on-screen instructions.



NOTE: To stop a diagnostic test, select **Cancel**.

Accessing HP PC Hardware Diagnostics Windows from the Start menu (select products only)

After HP PC Hardware Diagnostics Windows is installed, follow these steps to access it from the Start menu.

1. Select the **Start** button, and then select **All apps**.
2. Select **HP PC Hardware Diagnostics Windows**.
3. When the tool opens, select the type of diagnostic test that you want to run, and then follow the on-screen instructions.



NOTE: To stop a diagnostic test, select **Cancel**.

Downloading HP PC Hardware Diagnostics Windows

The HP PC Hardware Diagnostics Windows downloading instructions are provided in English only. You must use a Windows computer to download this tool because only .exe files are provided.

Downloading the latest HP PC Hardware Diagnostics Windows version from HP

To download HP PC Hardware Diagnostics Windows from HP, follow these steps.

1. Go to <http://www.hp.com/go/techcenter/pcdiags>. The HP PC Diagnostics home page is displayed.
2. Select **Diagnose PC Hardware issues in Windows**, scroll down to the expanded window that appears, and then select **Download**.
3. A pop-up that asks what you want to do with the file opens. Select **Open** or **Save As**. The latest version of the diagnostics tool opens or downloads to the selected location.

Downloading the HP PC Hardware Diagnostics Windows from the Microsoft Store

You can download the HP PC Hardware Diagnostics Windows from the Microsoft Store.

1. Select the Microsoft Store app on your desktop or select the **Search** icon in the taskbar, and then type `Microsoft Store` in the search box.
2. Type `HP PC Hardware Diagnostics Windows` in the **Microsoft Store** search box.
3. Follow the on-screen directions.

The tool downloads to the selected location.

Downloading HP Hardware Diagnostics Windows by product name or number (select products only)

You can download HP PC Hardware Diagnostics Windows by product name or number.



NOTE: For some products, you might have to download the software to a USB flash drive by using the product name or number.

1. Go to <http://www.hp.com/support>.
2. Select **Software and Drivers**, select your type of product, and then enter the product name or number in the search box that is displayed.
3. In the **Diagnostics** section, select **Download**, and then follow the on-screen instructions to select the specific Windows diagnostics version to be downloaded to your computer or USB flash drive.

The tool downloads to the selected location.

Installing HP PC Hardware Diagnostics Windows

To install HP PC Hardware Diagnostics Windows, navigate to the folder on your computer or the USB flash drive where the .exe file downloaded, double-click the .exe file, and then follow the on-screen instructions.

Using HP PC Hardware Diagnostics UEFI

HP PC Hardware Diagnostics Unified Extensible Firmware Interface (UEFI) allows you to run diagnostic tests to determine whether the computer hardware is functioning properly. The tool runs outside the operating system so that it can isolate hardware failures from issues that are caused by the operating system or other software components.



NOTE: For some products, you must use a Windows computer and a USB flash drive to download and create the HP UEFI support environment because only .exe files are provided. For more information, see [Downloading HP PC Hardware Diagnostics UEFI to a USB flash drive on page 79](#).

If your PC does not start in Windows, you can use HP PC Hardware Diagnostics UEFI to diagnose hardware issues.

Using an HP PC Hardware Diagnostics UEFI hardware failure ID code

When HP PC Hardware Diagnostics UEFI detects a failure that requires hardware replacement, a 24-digit failure ID code is generated.

For assistance in solving the problem, complete one of these tasks:

- Select **Contact HP**, accept the HP privacy disclaimer, and then use a mobile device to scan the failure ID code that appears on the next screen. The HP Customer Support - Service Center page appears with your failure ID and product number automatically filled in. Follow the on-screen instructions.
- Contact support, and provide the failure ID code.

Starting HP PC Hardware Diagnostics UEFI

To start HP PC Hardware Diagnostics UEFI, follow this procedure.

1. Turn on or restart the computer, and quickly press **esc**.
2. Press **f2**.

The BIOS searches three places for the diagnostic tools, in the following order:

- a. Connected USB flash drive



NOTE: To download the HP PC Hardware Diagnostics UEFI tool to a USB flash drive, see [Downloading the latest HP PC Hardware Diagnostics UEFI version on page 80](#).

- b. Hard drive
- c. BIOS

3. When the diagnostic tool opens, select the type of diagnostic test that you want to run, and then follow the on-screen instructions.

Starting HP PC Hardware Diagnostics UEFI through HP Hotkey Support software (select products only)

This section describes how to start HP PC Hardware Diagnostics UEFI through HP Hotkey Support software.



NOTE: You must disable Fast Boot to access HP PC Hardware Diagnostics UEFI from the HP System Information application.

To disable Fast Boot:

1. Turn on or restart the computer, and when the HP logo appears, press **f10** to enter Computer Setup.
2. Select **Advanced**, and then select **Boot Options**.
3. Clear **Fast Boot**.
4. Select **Save Changes and Exit**, and then select **Yes**.

To start HP PC Hardware Diagnostics UEFI through HP Hotkey Support software, follow this procedure:

1. From the **Start** menu, open the HP System Information Application or press **fn+esc**.
2. In HP System Information screen, select **Run System Diagnostics**, select **Yes** to run the application, and then select **Restart**.



IMPORTANT: To prevent loss of data, save your work in all open apps before restarting your computer.



NOTE: When the restart is complete, the computer opens the HP PC Hardware Diagnostics UEFI Application. Proceed with the troubleshooting tests.

Downloading HP PC Hardware Diagnostics UEFI to a USB flash drive

Downloading HP PC Hardware Diagnostics UEFI to a USB flash drive can be useful in some situations.

- HP PC Hardware Diagnostics UEFI is not included in the preinstallation image.
- HP PC Hardware Diagnostics UEFI is not included in the HP Tool partition.

- The hard drive is damaged.



NOTE: The HP PC Hardware Diagnostics UEFI downloading instructions are provided in English only, and you must use a Windows computer to download and create the HP UEFI support environment because only .exe files are provided.

Downloading the latest HP PC Hardware Diagnostics UEFI version

To download the latest HP PC Hardware Diagnostics UEFI version to a USB flash drive, follow these steps.

1. Go to <http://www.hp.com/go/techcenter/pcdiags>. The HP PC Diagnostics home page is displayed.
2. Select **Diagnose PC Hardware Issues outside of the OS**, scroll down to the expanded window that appears, and then select **Download**.
3. A pop-up that asks what you want to do with the file opens. Select **Open** or **Save As**. The latest version of the diagnostics tool opens or downloads to the selected location.

Downloading HP PC Hardware Diagnostics UEFI by product name or number (select products only)

You can download HP PC Hardware Diagnostics UEFI by product name or number (select products only) to a USB flash drive.



NOTE: For some products, you might have to download the software to a USB flash drive by using the product name or number.

1. Go to <http://www.hp.com/support>.
2. Enter the product name or number, select your computer, and then select your operating system.
3. In the **Diagnostics** section, follow the on-screen instructions to select and download the specific UEFI Diagnostics version for your computer.

Using Remote HP PC Hardware Diagnostics UEFI settings (select products only)

Remote HP PC Hardware Diagnostics UEFI is a firmware (BIOS) feature that downloads HP PC Hardware Diagnostics UEFI to your computer. It can then run the diagnostics on your computer, and it might upload results to a preconfigured server.

For more information about Remote HP PC Hardware Diagnostics UEFI, go to <http://www.hp.com/go/techcenter/pcdiags>, select **Diagnose Other Potential Issues**, scroll down to **Remote PC Hardware Diagnostics UEFI**, and then select **Learn More**.

Downloading Remote HP PC Hardware Diagnostics UEFI

Remote HP PC Hardware Diagnostics UEFI is also available as a SoftPaq that you can download to a server.

Downloading the latest Remote HP PC Hardware Diagnostics UEFI version

You can download the latest Remote HP PC Hardware Diagnostics UEFI version to a USB flash drive.

1. Go to <http://www.hp.com/go/techcenter/pcdiags>. The HP PC Diagnostics home page is displayed.

2. Select **Diagnose PC Hardware Issues outside of the OS**, scroll down to the expanded window that appears, and then select **Download**.
3. A pop-up that asks what you want to do with the file opens. Select **Open** or **Save As**. The latest version of the diagnostics tool opens or downloads to the selected location.

Downloading Remote HP PC Hardware Diagnostics UEFI by product name or number

You can download Remote HP PC Hardware Diagnostics UEFI by product name or number.



NOTE: For some products, you might have to download the software by using the product name or number.

1. Go to <http://www.hp.com/support>.
2. Select **Software and Drivers**, select your type of product, enter the product name or number in the search box that is displayed, select your computer, and then select your operating system.
3. In the **Diagnostics** section, follow the on-screen instructions to select and download the **Remote UEFI** version for the product.

Customizing Remote HP PC Hardware Diagnostics UEFI settings

Using the Remote HP PC Hardware Diagnostics setting in Computer Setup (BIOS), you can perform several customizations.

- Set a schedule for running diagnostics unattended. You can also start diagnostics immediately in interactive mode by selecting **Execute Remote HP PC Hardware Diagnostics UEFI**.
- Set the location for downloading the diagnostic tools. This feature provides access to the tools from the HP website or from a server that has been preconfigured for use. Your computer does not require the traditional local storage, such as a hard drive or USB flash drive, to run remote diagnostics.
- Set a location for storing the test results. You can also set the user name and password that you use for uploads.
- Display status information about the diagnostics run previously.

To customize Remote HP PC Hardware Diagnostics UEFI settings, follow these steps:

1. Turn on or restart the computer, and when the HP logo appears, press **f10** to enter Computer Setup.
2. Select **Advanced**, and then select **Settings**.
3. Make your customization selections.
4. Select **Main**, then select **Save Changes and Exit** to save your settings.

Your changes take effect when the computer restarts.

10 Specifications

This chapter provides specifications for your computer system.

Computer specifications

This section provides specifications for your computer. When you travel with your computer, the computer dimensions and weights, as well as input power ratings and operating specifications, provide helpful information.

Table 10-1 Computer specifications

	Metric	U.S.
Dimensions		
Width	385.0 mm	15.2 in
Depth	258.0 mm	10.2 in
Height (front to back)	23.0 mm	0.9 in
Weight	2.1 kg	4.6 lb
Input power		
Operating voltage and current	19.5 V DC @ 2.31 A - 45 W	
	19.5 V DC @ 3.33 A - 65 W	
	19.5 V DC @ 4.62 A - 90 W	
	19.5 V DC @ 7.70 A - 150 W	
	19.5 V DC @ 10.3 A - 200 W	
Temperature		
Operating	5°C to 35°C	41°F to 95°F
Nonoperating	-20°C to 60°C	-4°F to 140°F
Relative humidity (noncondensing)		
Operating	10% to 90%	
Nonoperating	5% to 95%	
Maximum altitude (unpressurized)		
Operating	-15 m to 3048 m	-50 ft to 10,000 ft
Nonoperating	-15 m to 12,192 m	-50 ft to 40,000 ft



NOTE: Applicable product safety standards specify thermal limits for plastic surfaces. The device operates well within this range of temperatures.

Display specifications

This section provides specifications for your display.

Table 10-2 Display specifications

	Metric	U.S.
Active diagonal size	39.6 cm	15.6 in
Resolution	1920 × 1080 (FHD) 3840 × 2160 (UHD)	
Surface treatment	Antiglare (FHD, UHD panels) Brightview (OLED panel)	
Brightness	250 nits (FHD, 45% NTSC panel) 300 nits (FHD, 72% NTSC/100% sRGB panels) 400 nits (UHD panel)	
Viewing angle	UWVA	
Backlight	WLED AMOLED	
Display panel interface	eDP	

Solid-state drive specifications

This section provides specifications for your SSDs.

Table 10-3 SSD specifications

	256 GB*	256 GB OPAL2*	512 GB*	512 GB TLC*	1 TB/2 TB*
Dimensions					
Height	2.3 mm	2.3 mm	2.3 mm	2.3 mm	2.3 mm
Length	80 mm	80 mm	80 mm	80 mm	80 mm
Width	22 mm	22 mm	22 mm	22 mm	22 mm
Weight	< 10 g	< 10 g	< 10 g	< 10 g	< 10 g
Interface type	PCIe	PCIe	PCIe	PCIe	PCIe
Ready time, maximum (to not busy)	1.0 ms	1.0 ms	< 1.0 ms	< 1.0 ms	1.0 ms
Access times, logical	0.1 ms	0.1 ms	0.1 ms	0.1 ms	0.1 ms
Transfer rate					
Sequential read	Up to 3100 MBps	Up to 3100 MBps	Up to 3500 MBps	Up to 6450 MBps	Up to 6400 MBps
Random read	Up to 300,000 IOPs	Up to 300,000 IOPs	Up to 300,000 IOPs	Up to 300,000 IOPs	Up to 300,000 IOPs

Table 10-3 SSD specifications (continued)

	256 GB*	256 GB OPAL2*	512 GB*	512 GB TLC*	1 TB/2 TB*
Sequential write	Up to 1200 MBps	Up to 1200 MBps	Up to 1600 MBps	Up to 3500 MBps	Up to 5000 MBps
Random write	Up to 100,000 IOPs	Up to 100,000 IOPs	Up to 100,000 IOPs	Up to 100,000 IOPs	Up to 100,000 IOPs
Total logical sectors	500,118,192	1,000,215,216	1,000,215,216	1,000,215,216	1 TB: 2,000,409,264 2 TB: 4,000,797,360
Operating temperature	0°C to 70°C (32°F to 158°F)	0°C to 70°C (32°F to 158°F)	0°C to 70°C (32°F to 158°F)	0°C to 70°C (32°F to 158°F)	0°C to 70°C (32°F to 158°F)

*Actual accessible capacity is less. Actual drive specifications might differ slightly.



NOTE: Certain restrictions and exclusions apply. Contact support for details.

11 Power cord set requirements

This chapter provides power cord requirements for countries and regions.

The wide-range input feature of the computer permits it to operate from any line voltage from 100 V AC to 120 V AC, or from 220 V AC to 240 V AC.

The 3-conductor power cord set included with the computer meets the requirements for use in the country or region where the equipment is purchased.

Power cord sets for use in other countries or regions must meet the requirements of the country and region where the computer is used.

Requirements for all countries

These power cord requirements are applicable to all countries and regions.

- The length of the power cord set must be at least **1.0 m** (3.3 ft) and no more than **2.0 m** (6.5 ft).
- All power cord sets must be approved by an acceptable accredited agency responsible for evaluation in the country or region where the power cord set will be used.
- The power cord sets must have a minimum current capacity of 10 A and a nominal voltage rating of 125 V AC or 250 V AC, as required by the power system of each country or region.
- The appliance coupler must meet the mechanical configuration of an EN 60 320/IEC 320 Standard Sheet C13 connector for mating with the appliance inlet on the back of the computer.

Requirements for specific countries and regions

To determine power cord requirements for specific countries and regions, use this table.

Table 11-1 Power cord requirements for specific countries and regions

Country/region	Accredited agency	Applicable note number
Argentina	IRAM	1
Australia	SAA	1
Austria	OVE	1
Belgium	CEBEC	1
Brazil	ABNT	1
Canada	CSA	2
Chile	IMQ	1
Denmark	DEMKO	1
Finland	FIMKO	1
France	UTE	1

Table 11-1 Power cord requirements for specific countries and regions (continued)

Country/region	Accredited agency	Applicable note number
Germany	VDE	1
India	BIS	1
Israel	SII	1
Italy	IMQ	1
Japan	JIS	3
Netherlands	KEMA	1
New Zealand	SANZ	1
Norway	NEMKO	1
The People's Republic of China	CCC	4
Saudi Arabia	SASO	7
Singapore	PSB	1
South Africa	SABS	1
South Korea	KTL	5
Sweden	SEMKO	1
Switzerland	SEV	1
Taiwan	BSMI	6
Thailand	TISI	1
United Kingdom	ASTA	1
United States	UL	2

1. The flexible cord must be Type HO5VV-F, 3-conductor, 0.75 mm² conductor size. Power cord set fittings (appliance coupler and wall plug) must bear the certification mark of the agency responsible for evaluation in the country or region where it will be used.
2. The flexible cord must be Type SVT/SJT or equivalent, No. 18 AWG, 3-conductor. The wall plug must be a 2-pole grounding type with a NEMA 5-15P (15 A, 125 V AC) or NEMA 6-15P (15 A, 250 V AC) configuration. CSA or C-UL mark. UL file number must be on each element.
3. The appliance coupler, flexible cord, and wall plug must bear a T mark and registration number in accordance with the Japanese Dentori Law. The flexible cord must be Type VCTF, 3-conductor, 0.75 mm² or 1.25 mm² conductor size. The wall plug must be a 2-pole grounding type with a Japanese Industrial Standard C8303 (7 A, 125 V AC) configuration.
4. The flexible cord must be Type RVV, 3-conductor, 0.75 mm² conductor size. Power cord set fittings (appliance coupler and wall plug) must bear the CCC certification mark.
5. The flexible cord must be Type HO5VV-F 3-conductor, 0.75 mm² conductor size. KTL logo and individual approval number must be on each element. Approval number and logo must be printed on a flag label.
6. The flexible cord must be Type HVCTF 3-conductor, 1.25 mm² conductor size. Power cord set fittings (appliance coupler, cable, and wall plug) must bear the BSMI certification mark.

7. For 127 V AC, the flexible cord must be Type SVT or SJT 3-conductor, 18 AWG, with plug NEMA 5-15P (15 A, 125 V AC), with UL and CSA or C-UL marks. For 240 V AC, the flexible cord must be Type H05VV-F 3-conductor, 0.75 mm² or 1.00 mm² conductor size, with plug BS 1363/A with BSI or ASTA marks.

12 Swelling or deformation of notebook battery

To protect your hardware from potential damage, HP recommends that if you are experiencing battery swelling, stop using the notebook until you can replace the battery.

You can contact HP to understand what battery replacement options are available. To learn more about lithium-ion batteries and the factors that can accelerate battery swelling, see https://support.hp.com/us-en/document/ish_6824662-6824706-16.

Swollen notebook batteries

You might notice that your notebook battery has become somewhat deformed or swollen over time. In some cases, the battery swelling might be significant enough to impact other components of the system including the touchpad, keyboard, and chassis.

Swollen battery is not a safety issue

A swollen battery does not present a safety issue. It is the result of the generation of gases per the normal degradation of the battery cell over time.

HP has worked closely with our battery cell suppliers and third-party industry experts to help minimize the potential for HP batteries to swell over time and to identify that swollen batteries are not a safety issue.

Discontinue using a swollen battery

To protect your hardware from potential damage, HP recommends that, if you are experiencing battery swelling, you stop using the notebook until the battery can be replaced.

You can contact <https://www.hp.com/go/contacthp> to understand what battery replacement options are available.

Replace a swollen battery

If a battery is under warranty, HP will replace the battery per the terms and conditions of the HP Worldwide Limited Warranty or applicable HP Care Packs.

For batteries no longer under warranty, contact HP to purchase a genuine HP replacement battery.

Minimize battery swelling

Multiple factors can accelerate battery swelling.

To help mitigate battery swelling over time, you can use either HP Adaptive Battery Optimizer (consumer notebooks) or HP Battery Health Manager (commercial notebooks) settings to improve battery longevity and performance for various use scenarios.

Adaptive Battery Optimizer (consumer notebooks)

Adaptive Battery Optimizer technology can help mitigate the factors that cause the battery to swell. It is available on select HP OMEN, HP Spectre, HP Pavilion, and HP ENVY notebook computers.

Adaptive Battery Optimizer has been available on select gaming notebooks since 2019 and select consumer notebooks since 2020. To learn more about enabling Adaptive Battery Optimizer on your HP notebook, see https://support.hp.com/us-en/document/ish_9908083-9908127-16.

HP Battery Health Manager (commercial notebooks)

HP Battery Health Manager provides an easy-to-manage solution to help mitigate factors that cause the battery to swell. It is available on select HP ProBook and HP EliteBook notebook computers.

HP Battery Health Manager is available on select commercial notebooks manufactured since 2016. To learn more about HP Battery Health Manager, see https://support.hp.com/us-en/document/ish_4449597-3519507-16.

13 Recycling

When a nonrechargeable or rechargeable battery has reached the end of its useful life, do not dispose of the battery in general household waste. Follow the local laws and regulations in your area for battery disposal.

HP encourages customers to recycle used electronic hardware, HP original print cartridges, and rechargeable batteries. For more information about recycling programs, see the HP website at <http://www.hp.com/recycle>.

Index

Symbols/Numerics

360 mode, identifying 15

A

AC adapter and battery light,
identifying 5, 7

AC adapters, spare part
numbers 22

action key, identifying 13

audio-out (headphone)/audio-in
(microphone) combo jack,
identifying 7

audio, product description 2

B

backup, creating 70

backups 70

battery

illustrated 19

spare part number 19

battery swelling 88

BIOS

determining version 73

downloading an update 74, 75

starting the Setup Utility 73

updating 73

Bluetooth label 16

boot order, changing 72

bottom components 15

bottom cover

removal 31

spare part number 31

buttons

left touchpad 10, 11

power 14

right touchpad 10, 11

C

calculator key, identifying 13

camera

identifying 9

camera light, identifying 9

camera privacy cover,

identifying 9

caps lock light 12

caring for your computer 27

cautions

electrostatic discharge 23, 24

cleaning your computer 27

caring for wood veneer 29

disinfecting 28

HP Easy Clean 27

removing dirt and debris 27

components

bottom 15

display 8

keyboard area 10

left side 6

lights 11

rear 14

right side 5

touchpad 10

computer major components 17

computer specifications 82

connectors

power 5-8

control zone 10

D

display

specifications 82, 83

display assembly

subcomponents 21

display back cover

illustrated 21

spare part number 21

display bezel

illustrated 21

spare part number 21

display cable

illustrated 21

spare part number 21

display components 8

display panel

illustrated 21

product description 1

spare part number 21

dual action keys, identifying 13

E

electrostatic discharge (ESD) 23,
24

preventing damage 23-25

esc key, identifying 13

F

fan

removal 44

spare part number 44

fn key, identifying 13

G

graphics, product description 1

grounding methods 23-25

guidelines

packaging 23, 29

transporting 23, 29

workstation 23

H

hard drive

product description 2

specifications 82

HDMI port

identifying 6

heat sink

removal 53

spare part numbers 53

hinge

illustrated 21

spare part number 21

hinge cover

illustrated 21

spare part number 21

HP PC Hardware Diagnostics UEFI

downloading 79

failure ID code 78

HP Hotkey Support

software 79

starting 78, 79

using 78

HP PC Hardware Diagnostics

Windows

accessing 76, 77

downloading 77

failure ID code 76

installing 78

using 76

HP Recovery media

recovery 71

HP Sure Recover 72

I

I/O board
removal 45
spare part number 45
illustrated parts catalog 17
infrared sensor board
illustrated 20
spare part number 20
integrated numeric keypad,
identifying 14
internal microphones,
identifying 9
IR sensor board
removal 55
spare part numbers 55

J

jacks
audio-out (headphone)/audio-in
(microphone) 7

K

keyboard
product description 3
keyboard with top cover
spare part numbers 68
keypad, integrated numeric 14
keys
action 13
calculator 13
esc 13
fn 13
num lock 14
Windows 13
Windows Copilot 14

L

labels
Bluetooth 16
regulatory 16
serial number 16
service 16
wireless certification 16
WLAN 16
left control zone, identifying 10
left side components 6
lights
AC adapter and battery 5, 7
camera 9
caps lock 12
microphone mute 12

mute 12
num lk 12
power 12
touchpad 10
lights, num lk 12
low blue light mode 8

M

magnetic pen attachment area,
identifying 5
memory module
product description 2
microphone
product description 2
microphone mute light,
identifying 12
model name 1
mute light, identifying 12

N

num lk light 12
num lk light, identifying 12
num lock key, identifying 14

O

operating system, product
description 4

P

packaging guidelines 23, 29
pointing device, product
description 3
ports
HDMI 6
product description 3
USB 6
USB Type-C power connector
and port with HP Sleep and
Charge and DisplayPort
output 6, 8
USB Type-C power connector
and Thunderbolt port with
HP Sleep and Charge and
DisplayPort output 5, 7
power button, identifying 14
power connector
identifying 5-8
power cord
requirements for all
countries 85
requirements for specific
countries and regions 85
set requirements 85

power cords, spare part
numbers 22
power light, identifying 12
power requirements, product
description 4
primary storage
product description 2
processor
product description 1
product description
audio 2
display panel 1
graphics 1
hard drive 2
keyboard 3
memory module 2
microphone 2
operating system 4
pointing device 3
ports 3
power requirements 4
primary storage 2
processors 1
product name 1
security 4
serviceability 4
solid-state drive 2
video 2
wireless 3
product name 1
product name and number,
computer 16

R

rear components 14
recovery 70
discs 71
media 71
USB flash drive 71
recovery media 70
creating using HP Cloud
Recovery Download
Tool 70
creating using Windows
tools 70
regulatory information
regulatory label 16
wireless certification labels 16
Remote HP PC Hardware
Diagnostics UEFI settings
customizing 81
using 80
removal and replacement
procedures 31, 41

- SSD 41
- restoring 70
- restoring and recovery
 - methods 71
- right control zone, identifying 10
- right side components 5
- S**
- Screw Kit, spare part number 22
- security, product description 4
- serial number, computer 16
- service labels, locating 16
- serviceability, product
 - description 4
- solid-state drive
 - product description 2
 - specifications 83
- spare part country codes 68
- speaker
 - removal 43
 - spare part number 43
- speakers 15
- special keys
 - identifying 13
 - using 13
- specifications
 - computer 82
 - display 82, 83
 - hard drive 82
 - solid-state drive 83
- SSD
 - illustrated 19
 - removal and replacement 41
 - spare part number 19
- static electricity 23, 24
- support information 29
- swelling or deformation of
 - notebook battery 88
- system board
 - illustrated 20
 - removal 50
 - spare part number 20
 - spare part numbers 50
- system restore 71
- system restore point, creating 70
- T**
- top cover/keyboard
 - illustrated 18
 - spare part number 18
- touchpad
 - brightness control 11
 - illustrated 19
 - removal 49

- settings 10
- spare part number 19
- spare part numbers 49
- volume control 11
- touchpad buttons
 - identifying 10, 11
- touchpad components 10
- touchpad light, identifying 10
- touchpad settings, adjusting 10
- touchpad zone, identifying 10, 11
- transporting guidelines 23, 29
- traveling with the computer 16

- U**
- USB port, identifying 6
- USB Type-C power connector and
 - port with HP Sleep and Charge
 - and DisplayPort output,
 - identifying 6, 8
- USB Type-C power connector and
 - Thunderbolt port with HP Sleep
 - and Charge and DisplayPort
 - output, identifying 5, 7

- V**
- vents, identifying 15
- video, product description 2

- W**
- wake-on-voice 8
- Windows
 - backup 70
 - recovery media 70
 - system restore point 70
- Windows Copilot key,
 - identifying 14
- Windows key, identifying 13
- Windows tools, using 70
- wireless antennas
 - illustrated 21
 - spare part number 21
- wireless antennas, identifying 9
- wireless certification label 16
- wireless, product description 3
- WLAN antennas, identifying 9
- WLAN device 16
- WLAN label 16
- WLAN module
 - removal 47
 - spare part numbers 47
- workstation guidelines 23