



POLY STUDIO E70

ENGLISH

Poly Studio E70 Product Specifications
Power: PoE+, 802.11at, Class 4
Camera resolution: 2160p, 4K UHD (3840 x 2160)
Camera type: Dual-lens
Camera range: 25ft/7.62m
Operating temperature: 32 to 104°F
Minimum dimensions: 12.6 x 4.02 x 3.51 in

BAHASA INDONESIA

Spesifikasi Produk Poly Studio E70
Daya: PoE+, 802.11at, Kelas 4
Resolusi kamera: 2160p, 4K UHD (3840 x 2160)
Jenis kamera: Lensa-ganda
Rentang kamera: 25ft/7.62m
Suhu pengoperasian: 0 hingga 40°C
Dimensi minimum: 12,6 inci x 4,02 inci x 3,51 inci

ENGLISH

Instructions for Use

Privacy Shutter

The privacy shutter automatically opens and closes depending on the state of the connected video system.

BAHASA INDONESIA

Petunjuk Penggunaan

Shutter Privasi

Shutte privasi secara otomatis membuka dan menutup tergantung pada kondisi sistem video yang terhubung.

ENGLISH

Poly Studio E70 Hardware
❶ Dual cameras
❷ LED indicators

BAHASA INDONESIA

Perangkat Keras Poly Studio E70
❶ Kamera ganda
❷ Indikator LED

ENGLISH

Poly Studio E70 Ports
❶ Reset button
❷ Ethernet port (Can be used to provide power to the camera)
❸ USB-C port
❹ Power cord port

BAHASA INDONESIA

Port Poly Studio E70
❶ Tombol Reset (Atur Ulang)
❷ Port Ethernet (Dapat digunakan untuk memberi daya pada kamera)
❸ Port USB-C
❹ Port kabel Daya

ENGLISH

Maintenance Instructions
Poly recommends that you regularly clean the screen on all touch-enabled phones and devices located in high-use spaces, such as conference rooms and lobbies.
1. Unplug all cables from the phone or device.
2. Spray a medicinal isopropyl alcohol and water solution of 70:30 onto a clean, dry, microfiber cloth, making sure to not oversaturate the cloth. Should oversaturation occur, squeeze out any excess liquid before wiping the surface.
3. Quickly wipe the screen with the dampened microfiber cloth. Always use the dampened cloth with the alcohol solution to clean screens, and don't let cleaning solution pool on the surface. Don't use chemicals to clean the screen.
4. Let the touchscreen and surrounding areas air-dry completely before reconnecting any cables.
Note: You can also use an alcohol cleaning solution of up to 99% to clean touchscreens to reduce the risk of seepage and quicken the drying time.

BAHASA INDONESIA

Petunjuk Pemeliharaan
Poly menyarankan agar Anda membersihkan layar secara rutin pada semua telepon dan perangkat berkemampuan sentuh yang berada di ruangan yang sering digunakan, seperti ruang konferensi dan lobi.
1. Lepaskan semua kabel dari telepon atau perangkat.
2. Semprotkan larutan obat isopropil alkohol dan air dengan perbandingan 70:30 pada kain mikrofiber yang bersih dan kering, pastikan kain tidak terlalu basah. Jika terjadi penyerapan berlebih, peras sisa cairan sebelum menyeka permukaan.
3. Seka layar dengan cepat menggunakan kain mikrofiber yang dibasahi. Selalu gunakan kain yang dibasahi dengan larutan alkohol untuk membersihkan layar, dan jangan biarkan larutan pembersih menggenang di permukaan. Jangan gunakan bahan kimia untuk membersihkan layar.
4. Biarkan layar sentuh dan area sekitarnya benar-benar kering sebelum menghubungkan kembali semua kabel.
Catatan: Anda juga dapat menggunakan larutan pembersih beralkohol hingga 99% untuk membersihkan layar sentuh guna mengurangi risiko rembesan dan mempercepat waktu pengeringan.

support.hp.com/poly

Poly Studio E70

Nomor Registrasi di
Kementerian Perdagangan: IMKG.205.01.2024

Importir: PT. Hewlett-Packard Indonesia

Alamat: Gedung Perkantoran Prudential Centre,Kota Kasablanka Lantai 9,JL. Casablanca Kav. 88 Menteng Dalam, Tebet .12870 Jakarta Selatan, Indonesia

© 2024 Poly. All trademarks are the property of their respective owners.

P00116-001A 01.24
RMN/型號/型号: P025

ENGLISH

LED Status Indicators
Pulsing white - Boot initialization is in progress
Solid white (50% brightness) - Powered on but disconnected from video system; sleep mode
Solid white (100% brightness) - Powered on and connected to the video system
Solid green - In a call or the camera is active
Pulsing amber - Firmware update or factory reset in progress

BAHASA INDONESIA

Indikator Status LED
Bergetar putih - Inisialisasi booting sedang berlangsung
Putih solid (kecerahan 50%) - Dinyalakan namun terputus dari sistem video; mode tidur
Putih solid (kecerahan 100%) - Dinyalakan dan terhubung ke sistem video
Hijau solid - Sedang dalam panggilan atau kamera aktif
Bergetar kuning - Pembaruan firmware atau pemulihan pabrik sedang berlangsung